



© 2012 Koninklijke Philips Electronics N.V.  
All rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips  
Electronics N.V. or their respective owners.

DC290B\_37\_QSG\_V2.0



Register your product and get support at  
[www.philips.com/welcome](http://www.philips.com/welcome)


Docking Entertainment System  
DC290B



## Quick start guide

- 1 Connect
- 2 Setup
- 3 Enjoy

## What's in the box



Main unit



Remote control



MP3 link cable




User Manual  
Quick Start Guide

## 1 Connect

### A Connect power

- 1 Connect the AC power cord to the wall outlet.



**PHILIPS**

EN

## 2 Setup

### A Set time and date

- 1 In standby mode, press and hold **SET TIME/PROG** for 2 seconds.  
↳ Hour digits start to blink.
- 2 Press **OK/▶II** to select the 12/24 hour format.
- 3 Press **◀▶I** to set the hour.
- 4 Press **SET TIME/PROG** to confirm.  
↳ The minute digits begin to blink.
- 5 Repeat steps 3-4 to set the minute, year, month, and day.

### B Set the alarm timer

You can set two alarms which go off at different time.

- 1 Ensure that you have set the clock correctly.
- 2 Press and hold **ALM 1** or **ALM 2** for 2 seconds.

↳ [AL 1] or [AL 2] begin to blink.

- 3 Press **SOURCE** on the top panel to select an alarm sound source: iPod/iPhone, FM tuner, or buzzer.
- 4 Press **ALM 1** or **ALM 2**.  
↳ The hour digits begin to blink.
- 5 Press **◀▶I** repeatedly to set the hour.
- 6 Press **ALM 1** or **ALM 2** to confirm.  
↳ The minute digits begin to blink.
- 7 Repeat steps 5-6 to set the minute.
- 8 Repeat steps 5-6 to select whether to ring alarm the whole week, on weekdays, or at weekend.
- 9 Repeat steps 5-6 to set the alarm volume.

#### \* Tip

- If you set iPhone/iPod playlist as the sound source, you must create a playlist in iTunes called "PHILIPS" and import it to your iPhone/iPod.
- If no playlist is created in the iPod/iPhone or there is no song in the playlist, the unit will wake to songs in the iPod/iPhone.

## 2 Setup

### Activate and deactivate the alarm timer

- 1 Press **ALM 1** or **ALM 2** repeatedly to activate or deactivate the timer.  
↳ If the timer is activated, [**AL 1**] or [**AL 2**] is displayed.  
↳ If the timer is deactivated, [**AL 1**] or [**AL 2**] disappears.

### Repeat alarm

- 1 When the alarm rings, press **BRIGHTNESS/REP ALM**.  
↳ The alarm repeats ringing minutes later.

#### \* Tip

- ↳ You can press **◀▶I** to adjust the interval to repeat alarm.


### Stop alarm ring

- 1 When the alarm rings, press the corresponding **ALM 1** or **ALM 2**.  
↳ The alarm stops but the alarm settings remain.


## 3 Enjoy

### A Play from iPod/iPhone

- 1 Lift up the iPhone/iPod dock on the top panel.



- 2 Place the iPhone/iPod into the dock.



## 3 Enjoy

- 3 Press **iPhone/iPod** to select iPod/iPhone source.

↳ The connected iPod/iPhone plays automatically.

- To pause/resume play, press **OK/▶II**.
- To skip to a track, press **◀▶I**.
- To search during play, press and hold **◀▶I**, then release to resume normal play.
- To go back to the previous iPod/iPhone menu, press **MENU**. To scroll through the menu, press **◀▶I**.
- To confirm a selection, press **OK/▶II**.  
↳ If no key is pressed for more than 10 seconds, **OK/▶II** acts back as the play/pause key.

### B Program and listen to radio stations

- 1 In the tuner mode, press and hold **SET TIME/PROG** for more than 2 seconds to activate automatic program mode.  
↳ [AUTO] (auto) is displayed.  
↳ All available stations are programmed in the order of waveband reception strength.  
↳ The first programmed radio station is broadcast automatically.
- 2 Press **◀▶I** to select a preset number.

#### \* Tip

- Detailed functions and features are described in the user manual.