

Important safety instructions

Warning

- The Electrical network is classified as hazardous. The only way to power down the charger is to unplug the power supply from the electrical outlet. Ensure that the electrical outlet is always easily accessible.
- Refer to safety information before using the product.
- This product complies with European R&TTE directive 1999/5/EC.
- Use only the power supply listed in the user instructions.
- Use only the batteries listed in the user instructions.
- Use only the batteries listed in the user instructions.
- Do not allow the product to come into contact with liquids.
- Risk of explosion if battery is replaced by an incorrect type.
- Dispose of used batteries according to the instructions.
- When the handset rings or when the handsfree is activated, keep the handset away from your ear to avoid hearing damage.

1 Overview

In call

- MENU OK** Enter the option menu
- Adjust the volume**
- End calls**
- Mute/unmute the microphone**
- #** Enter a pause

Standby


- MENU OK** Access the main menu
- Phonebook**
- Call log**
- Make and receive calls**
- *INT** Make intercom call
- Lock/unlock the keypad**
- R** Recall key (network dependent)

In menu

- MENU OK** Confirm / Enter the option menu / Select
- REDIAL C** Cancel
- Up / down**
- Exit menu**

In text input


- REDIAL C** Delete text
- Enter a space**



Display icons

- Signal strength bars**: It displays the connection between the handset and the base. The more the bars are shown, the better the connection is.
- Incoming call icon**: It remains steadily on when browsing incoming calls in the call log.
- Outgoing call icon**: It indicates an outgoing call in the redial list.
- Missed call icon**: It flashes when there is a new missed call or when browsing new missed calls. It remains steadily on when browsing the missed calls in call log that are already read.
- Receiving call icon**: It flashes when receiving incoming call. It remains steadily on during a call.
- Ringer off icon**: The ringer is off.
- Voice messages indicator**: flashes for new messages, is steady for reviewed messages. * This is network dependent
- Volume icon**: It displays when you scroll up/down a list or increase and decrease the volume.
- More digits icon**: There are more digits on the right. Press **REDIAL C** to read.

2 Connect



Multi-handset version only.

PHILIPS

Short user manual




D150

Register your product and get support at www.philips.com/welcome


© 2013 Koninklijke Philips Electronics N.V. All rights reserved.
N.V. or their respective owners.
the copyright owner. Trademarks are the property of Koninklijke Philips Electronics N.V. or their respective owners.
Reproduction in whole or in part is prohibited without the written consent of the copyright owner. Trademarks are the property of Koninklijke Philips Electronics N.V. or their respective owners.
Directive 2002/96/EC.
the product is covered by the European
is attached to a product it means that
When this crossed-out wheeled bin symbol
is attached to a product it means that
the product is covered by the European
Directive 2002/96/EC.
Reproduction in whole or in part is
prohibited without the written consent of
the copyright owner. Trademarks are the
property of Koninklijke Philips Electronics
N.V. or their respective owners.
All rights reserved.
© 2013 Koninklijke Philips Electronics N.V.
WK1248

CE 0168



3 Get started


Insert batteries



Configure your phone

- When using your phone for the first time, you see a welcome message (country dependent).
- Set the country and language if prompted.
- Set the date and time.
 - If the time is in 12-hour format, press / key to select [AM] or [PM] (country dependent).

Charge your phone



Charge 8 hours

> 70%

10% - 40%

40% - 70%

< 10%

Flashing: low battery

Scrolling: charging in progress

4 Enjoy

Phonebook

Add record

- Press .
- Select **[PHONEBOOK]** > **[ADD NEW]**.
- Follow on-screen instructions.

Call from the phonebook

- Press .
- Select a record and press .

Direct access memory

You have 2 direct access memories (Keys 1 and 2). To dial the saved phone number automatically, press and hold on the keys in standby mode. Depending on your country, keys 1 and 2 are preset to **[1_VOICEMAIL]** (voice mail number) and **[2_INFO SVC]** (information service number) of your network operator respectively (network dependent).

Call log

Call from the call log

- Press .
- Select a record and press .

Add record

- Press > > **[SAVE NUMBER]**.
- Follow on-screen instructions.

Delete record

- Press > > **[DELETE]**.
- Follow on-screen instructions.

Redial list

Call from the redial list

- Press .
- Select a record and press .

Add record

- Press > > **[SAVE NUMBER]**.
- Follow on-screen instructions.

Delete record

- Press > > **[DELETE]**.
- Follow on-screen instructions.

Register additional handsets

You can register additional handsets to the base station.

- Press and hold on the base station for 5 seconds.
- Press .
- Select **[SERVICES]** > **[REGISTER]**, then press to confirm.
- Enter the system PIN/passcode (0000).
- Press to confirm the PIN/passcode.
 - Registration is completed in less than 2 minutes.

Restore default settings

You can reset your phone settings to the original factory settings.

- Press .
- Select **[SERVICES]** > **[RESET]**, then press to confirm.
- Follow on-screen instructions.

Note

- You may recall the original PIN/passcode by following this procedure.

Technical data

Battery

- Philips: 2 x AAA NiMH 1.2V Rechargeable 550 mAh batteries

Use only the supplied batteries.

Adapter

Base and charger:

| | | |
|----------|-----------------|----------------|
| Philips: | S0031B0600040 | SSW-1920UK-2 |
| Input: | 100-240 V | 100-240 V |
| | 50/60 Hz 0.15 A | 50/60 Hz 0.2 A |
| Output: | 6 V 400 mA | 6 V 500 mA |

Phonebook with 50 entries

Call log with 20 entries

Talk time: 16 hours

Standby time: 250 hours

Note

- You can install a DSL (digital subscriber line) filter to prevent noise and caller ID problems caused by the DSL interference.
- You can find the Declaration of Conformity on www.p4c.philips.com.

? Frequently asked questions

No signal bar is displayed on the screen.

- The handset is out of range. Move it closer to the base station.
- If the handset displays **[UNREGISTERED]**, register your handset.

If I fail to pair (register) the additional handsets to the base station, what do I do?

Your base memory is full. Access > **[SERVICES]** > **[UNREGISTER]** to unregister the unused handsets and try again.

I have chosen a wrong language which I cannot read, what do I do?

- Press to go back to the standby screen.
- Press to access the main menu screen.
- The following options will appear on the screen:

| |
|--|
| [PHONE SETUP] > [LANGUAGE] |
| [CONFIG.TEL.] > [LANGUE] |
| [TEL.-SETUP] > [SPRACHE] |
| [CONF.TELEF.] > [LINGUA] |

- Select it to access the language options.

- Select your own language.

My handset is in searching status, what do I do?

- Make sure that the base station has power supply.
- Register the handset to the base station.
- Move the handset closer to the base station.

I cannot change the settings of my voice mail, what do I do?

The voice mail service is managed by your service provider but not the phone itself. Contact your service provider to change the settings.

No display

- Make sure the batteries are charged.
- Make sure there are power and phone connections.

The handset on the charger does not charge.

- Make sure the batteries are inserted correctly.
- Make sure the handset is placed properly on the charger. The battery icon animates when charging.
- Make sure the docking tone setting is turned on. When the handset is placed correctly on the charger, you can hear a docking tone.
- The charging contacts are dirty. Disconnect the power supply first and clean the contacts with a damp cloth.
- Purchase new ones with the same specifications.

Bad audio (crackles, echo, etc.)

- The handset is nearly out of range. Move it closer to the base station.
- The phone receives interference from the nearby electrical appliances. Move the base station away from them.
- The phone is at a location with thick walls. Move the base away from them.

The handset does not ring.

Make sure the handset ringtone is turned on.

The caller ID does not display.

- The service is not activated. Check with your service provider.
- The caller's information is withheld or unavailable.