

Register your product and get support at

www.philips.com/support

D130

D135



Short user manual

PHILIPS

Important safety instructions



Warning

- The Electrical network is classified as hazardous. The only way to power down the charger is to unplug the power supply from the electrical outlet. Ensure that the electrical outlet is always easily accessible.
- Refer to safety information before using the product.
- This product complies with European R&TTE directive 1999/5/EC.
- Use only the power supply listed in the user instructions.
- Use only the batteries listed in the user instructions.
- Do not allow the product to come into contact with liquids.
- Risk of explosion if battery is replaced by an incorrect type.
- Dispose of used batteries according to the instructions.
- When the handset rings or when the handsfree is activated, keep the handset away from your ear to avoid hearing damage.

1 Overview

In call

MENU OK Enter the option menu.

REDIAL C Access the redial list.

Up / down Adjust the volume.

End calls.

Enter a pause (press and hold).

R Recall (network dependent).

Mute/unmute the microphone.

In menu

MENU OK Confirm / Select / Enter the option menu.

REDIAL C Cancel / back

Up / down

Exit menu.

Standby

MENU OK Access the main menu.

REDIAL C Access the redial list.

Phonebook

Call log

Make and receive calls.

Switch the handset on or off (press and hold).

***INT** Make intercom call (press and hold).


0 Lock/unlock the keypad (press and hold).

D135 only: Press to play new message from the answer machine. / Access to the answer machine menu.

In text input

REDIAL C Delete text.

0 Enter a space.



Display icons

Signal strength icon It shows the connection status between the handset and base station. The more bars are shown, the better the signal strength is.

Incoming call icon It remains steadily on when browsing incoming calls in the call log.

Outgoing call icon It indicates an outgoing call in the redial list.

Missed call icon It flashes when there is a new missed call or when browsing new missed calls. It remains steadily on when browsing the missed calls in call log that are already read.

Receiving call icon It flashes when receiving incoming call. It remains steadily on during a call.

Ringer off icon The ringer is off.



D135 only: Answering machine icon D135 only: Answering machine: it flashes when there is a new message or when the memory is full. It is displayed when the telephone answering machine is turned on.

Voice messages indicator icon Voice messages indicator: flashes for new messages, is steady for reviewed messages. * This is network dependent.

Volume icon It is displayed when you scroll up/down a list or increase and decrease the volume.

More digits icon There are more digits on the right. Press **REDIAL C** to read.


2 Connect



Multi-handset version
only.

3 Get started

Insert batteries



Configure your phone

- 1 When using your phone for the first time, you see a welcome message (country dependent).
- 2 Set the country and language if prompted.
- 3 Set the date and time.
 - If the time is in 12-hour format, press / to select **[AM]** or **[PM]** (country dependent).

Charge your phone



> 70%

40% - 70%

10% - 40%

Flashing: low battery

Scrolling: charging in progress

4 Enjoy

Phonebook

Add record

- 1 Press > **[PHONEBOOK]** > **[ADD NEW]**.
- 2 Select **[PHONEBOOK]** > **[ADD NEW]**.
- 3 Follow on-screen instructions.

Call from the phonebook

- 1 Press .
- 2 Select a record and press .

Direct access memory

You have up to 2 direct access memories (keys 1 and 2). To dial the saved phone number automatically, press and hold on the keys in standby mode. Depending on your country, keys 1 and 2 are preset to the voice mail number and information service number of your service provider respectively (network dependent).

Call log

Call from the call log

- 1 Press .
- 2 Select a record and press .

View record

Press > > **[VIEW]**.

Save record

- 1 Press > > **[SAVE NUMBER]**.
- 2 Follow on-screen instructions.

Delete record

- 1 Press > > **[DELETE]**.
- 2 Follow on-screen instructions.

Redial list

Call from the redial list

- 1 Press .
- 2 Select a record and press .

Save record

- 1 Press > > **[SAVE NUMBER]**.
- 2 Follow on-screen instructions.

Delete record

- 1 Press > > **[DELETE]**.
- 2 Follow on-screen instructions.

Telephone answering machine (for D135 only)

Record an announcement

- 1 Press > **[ANSW MACHINE]** > **[ANNOUNCEMENT]**.
- 2 Follow on-screen instructions.

Listen to the incoming messages

Press > **[ANSW MACHINE]** > **[PLAY]**.

Delete an incoming message

- 1 When you listen to the message, press to enter the options menu.
- 2 Select **[DELETE]**, then press to confirm.

Register additional handsets

You can register additional handsets to the base station.

- 1 Press and hold on the base station for 5 seconds.
- 2 Press .
- 3 Select **[SERVICES]** > **[REGISTER]**, then press to confirm.
- 4 Enter the system PIN/passcode (0000).
- 5 Press to confirm the PIN/passcode.
→ Registration is complete in less than 2 minutes.

Restore default settings

You can reset your phone settings to the original factory settings.

- 1 Press .
- 2 Select **[SERVICES]** > **[RESET]**, then press to confirm.
- 3 Follow on-screen instructions.



Note

- You may recall the original PIN/passcode by following this procedure.



Technical data

Battery

- Philips: 2 x AAA NiMH 1.2 V Rechargeable 300 mAh batteries

Use only the supplied batteries.

Adapter (base and charger)

	Input:	Output:
Meic:	100-240 V~	6 Vdc
MN-A102-U130	50/60 Hz 200 mA	400 mA
Tenpao:	100-240 V~	6 Vdc
S003IB0600040	50/60 Hz 150 mA	400 mA

Phonebook with 50 entries

Call log with 20 entries

Talk time: 10 hours

Standby time: 200 hours



Note

- You can install a DSL (digital subscriber line) filter to prevent noise and caller ID problems caused by the DSL interference.
- You can find the Declaration of Conformity on www.p4c.philips.com.

? Frequently asked questions

No signal bar is displayed on the screen.

- The handset is out of range. Move it closer to the base station.
- If the handset displays **[UNREGISTERED]**, register your handset. (See the section on "Register additional handsets").

If I fail to pair (register) the additional handsets to the base station, what do I do?

- Your base memory is full. Access **MENU** **OK** > **[SERVICES]** > **[UNREGISTER]** to unregister the unused handsets and try again.
- If registration fails, unplug the power adapter from the base station and plug it back. Wait for 15 seconds, and then repeat the registration procedure.

My handset is in searching or unavailable status, what do I do?

- Make sure that the base station has power supply.
- Register the handset to the base station.
- Move the handset closer to the base station.

I cannot change the settings of my voice mail, what do I do?

The voice mail service is managed by your service provider but not the phone itself. Contact your service provider to change the settings.

No display

- Make sure the batteries are charged.
- Make sure there are power and phone connections.

The handset on the charger does not charge.

- Make sure the batteries are inserted correctly.
- Make sure the handset is placed properly on the charger. The battery icon animates when charging.
- Make sure the docking tone setting is turned on. When the handset is placed correctly on the charger, you can hear a docking tone.
- The charging contacts are dirty. Disconnect the power supply first and clean the contacts with a damp cloth.
- Batteries are defective. Purchase new ones with the same specifications.

Bad audio (crackles, echo, etc.)


- The handset is nearly out of range. Move it closer to the base station.
- The phone receives interference from the nearby electrical appliances. Move the base station away from them.
- The phone is at a location with thick walls. Move the base away from them.

The handset does not ring.

Make sure the handset ringtone is turned on.

The caller ID does not display.

- The service is not activated. Check with your service provider.
- The caller's information is withheld or unavailable.



www.philips.com/support

To access the user instructions online, use the reference model number written on the product label at the bottom of the base station.



This symbol on a product means that the product is covered by European Directive 2012/19/EU.

2015 © Gibson Innovations Limited.
All rights reserved.

This product has been manufactured by, and is sold under the responsibility of Gibson Innovations Ltd., and Gibson Innovations Ltd. is the warrantor in relation to this product. Philips and the Philips Shield Emblem are registered trademarks of Koninklijke Philips N.V. and are used under license from Koninklijke Philips N.V.

CE 0168



UMS_D130/135
90_EN_V1.0
WK15225