

Register your product and get support at
www.philips.com/welcome

Docking Entertainment System

DCB210



Quick start guide

1 Connect



2 Setup

3 Enjoy

PHILIPS

EN

What's in the box



Main unit

Power adaptor

MP3 link cable


Quick Start Guide

User Manual

1 Connect


A Prepare DAB/FM antenna

- 1 Fully extend the antenna and fix it to the wall as shown.



B Connect power

- 1 Connect the power adaptor to
 - the **DC IN** jack on the rear of the main unit
 - the power socket.



2 Setup

A Set clock

- 1 In standby mode, press and hold **TIME SET/AUTO SCAN** for 2 seconds.
↳ **[SYNC ON]** begins to blink.
- 2 Press **TUNING +/-** or **PRESET +/-** to select a sync mode and press **TIME SET/AUTO SCAN** to confirm.
↳ The 24H or 12H begins to blink.
- 3 Press **TUNING +/-** to select the clock format .
↳ The hour digits begin to blink.
- 4 Press **TUNING +/-** to set the hour.
- 5 Press **TIME SET/AUTO SCAN**.
↳ The minute digits begin to blink.
- 6 Press **TUNING +/-** to set the minute.
- 7 Press **TIME SET/AUTO SCAN** to confirm.
- 8 Press **TUNING +/-** to set the year, month, and date.
- 9 Press **TIME SET/AUTO SCAN** to confirm.


B Set the alarm timer

- 1 Ensure that you have set the clock correctly.
- 2 Press and hold **ALARM 1** or **ALARM 2** for 2 seconds.
↳ The hour digits begin to blink.
- 3 Press **TUNING +/-** to set the hour.
- 4 Press **ALARM 1** or **ALARM 2** again.
↳ The minute digits begin to blink.
- 5 Press **TUNING +/-** to set the minute.
- 6 Press **ALARM 1** or **ALARM 2** to confirm.
↳ The weekdays begin to blink.
- 7 Press **TUNING +/-** to select whether to ring alarm on weekdays or weekend.
- 8 Press **ALARM 1** or **ALARM 2** to confirm.
- 9 Press **TUNING +/-** to select alarm volume.
- 10 Press **ALARM 1** or **ALARM 2** to confirm.

2 Setup

Set alarm mode

- 1 Adjust the **WAKE TO iPod/DAB/FM/BUZZ** control to select the source for the alarm.
 - ↳ When the alarm time comes, the selected iPod, DAB, FM radio or buzzer turns on.



Activate and deactivate the alarm timer

- 1 Press **ALARM 1** or **ALARM 2** repeatedly to activate/deactivate the timer.

* Tip

- If the alarm timer is turned on, **AL1/AL2** is displayed.
- If the alarm timer is turned off, **AL** disappears.

Repeat alarm

- 1 When the alarm rings, press **REPEAT ALARM/BRIGHTNESS CONTROL**.
 - ↳ The alarm repeats ringing minutes later.

* Tip

- You can press **TUNING+/-** to adjust interval (5 - 15 minutes) to repeat alarm.

Stop alarm ring

- 1 When the alarm rings, press the corresponding **ALARM 1** or **ALARM 2**.
 - ↳ The alarm stops but the alarm settings remain.

Reset the preset radio stations


- 1 In **FM/DAB** mode, during broadcasting, press and hold **INFO/MENU**.
 - ↳ **[SELECT FACTORY]** is displayed on the screen.
- 2 Press **SELECT**.
 - ↳ **[CONFIRM Reset]** is displayed on the screen.
- 3 Press **SELECT** to confirm.
 - ↳ All preset radio stations are cleared.

3

Enjoy

A Play from iPod

- 1 Push to open the dock compartment.



- 2 Place the iPod in the dock.



- 3 Press **SOURCE** repeatedly to select iPod source.

↳ The connected iPod plays automatically.

- To pause/resume play, press ►||.
- To skip to a track, press |◀◀/▶▶|.
- To search during play, press and hold |◀◀/▶▶|, then release to resume normal play.

B Program and listen to DAB/FM radio stations

- 1 Press **SOURCE** repeatedly to select DAB/FM radio
- 2 In the DAB/FM tuner mode, press and hold **TIME SET/AUTO SCAN** for more than 2 seconds to activate automatic program mode.

- ↳ All available stations are programmed in the order of waveband reception strength.
- ↳ The first programmed radio station is broadcast automatically.

- 2 Press **PRESET +/-** to select a preset number.
- 3 Press and hold **SELECT** for two seconds.
 - ↳ The preset number of the saved station appears.

* Tip

- Detailed functions and features are described in the user manual.



© Royal Philips Electronics N.V. 2009
All rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips
Electronics N.V. or their respective owners.

Printed in China
DCB210_05_QSG_V2.0

