


1. Installation


(1) If the support holders have been installed on the massager: unfold the support holders and place it on the ground, and remove the dust cover. While lifting the handle, press the massage turntable down until the massager unfolds normally.

(2) If the support holders are not installed on the massager: remove the dust cover and place the massager flat on the ground. While pressing one side of the massage turntable, lift the upper edge of the massager on the same side and lift it up to expand the massager to a certain angle; repeat the above on the other side to fully expand the massager. Then install the support holders according to the prompts on the massager.



2. Add water and power on


Place the massager on a flat surface, add an appropriate amount of water (it is recommended to add warm water at about 35°C to reduce waiting time), and connect to a 220-240V~/50-60Hz household power supply. After power on, the buzzer makes three beeps, the indicator light in the massager flashes slowly, and massager enters the standby state.



1


3. Turn on the device and switch levels

(1) In standby state, hold the power button for 2 seconds to start the massager in Level I (40°C); press the power button again to switch to Level II (43°C); and then press the power button again to switch to Level III (46°C). Press the button to cycle through the three levels in sequence. When the water temperature reaches the specified temperature, the massage function will automatically turn on, and end after 30 minutes.






4. Turn off the device


In any working mode, hold the power button for 2 seconds, the buzzer will sound for 1.5 seconds, and then end the current mode and enter the standby state.





5. Use the remote control

After power on, aim the remote control into the massager and press  button. The buzzer sounds once, the indicator light in the massager displays in green, and the massager turns on Level I;

In any modes, aim the remote control into the massager and press    button, and the massager will switch to the corresponding levels.

In any modes, aim the remote control into the massager and press  button to turn on / off the massage function;

In any modes, aim the remote control into the massager and press  button. The buzzer sounds for 1.5 seconds, and then end the current mode and enter the standby state.



2

6. Storage


(1) Pour out the water in the massager and let it dry;

(2) Place the massager upside down on the ground with a soft carpet;

(3) Press down on both sides of the massager bottom cover at the same time to fold it;

(4) Pull gently the support holders inward to fold it close to the bottom cover;

(5) Put the massager upwards with the dust cover, put the remote control in place, and the storage is complete.



! 1. It is recommended that do not add water exceeding 46°C to prevent scalding feet. For your safety, when the water temperature exceeds 50°C, the device stops heating, accompanied by 10 warning sounds, and the indicator light flashes red 10 times and then it enters shutdown state. After the water temperature drops below 48°C, the device enters standby mode.

2. It is recommended to drink a 250ml cup of warm water before and after use.

3. In general, the foot spa for 30 to 40 minutes is better. Please drink the appropriate amount of warm water during use.


4. Every Philips foot massager is qualified in strict water testing before delivery. It is normal for any residual water stains in the product that you receive. Please feel free to use it.

3

1. 安裝按摩器


(1) 支撐架已裝在機器上：只需展開支撐架放於地面，取下防塵蓋，一邊提起手柄，一邊向下按壓按摩轉盤，直到正常展開。

(2) 支撐架沒有裝在機器上：取下防塵蓋，按摩器平放於地面，一邊按住按摩轉盤一側，一邊提住按摩器同側上沿往上提，讓按摩器展開一定角度；換一側重複上述動作，把按摩器完全展開；然後根據機器上的標示裝上支撐架即可。



2. 加水通電

將機器平放，加適量水（建議加35°C左右溫水，以減少您等待時間），通220-240V~/50-60Hz家用電源，接通電源後，蜂鳴器發出三聲響聲（滴—滴—滴—），按摩器內指示燈緩慢閃爍，進入待機狀態。



4



請在以下網站鏈接中了解詳情
www.philips.com

本手冊內容與實物可能存在差異，請以實物為準，如產品有任何更新恕不另行通知。


©2023 AquaShield
All rights reserved
Philips and the Philips Shield Emblem are registered trademarks of Koninklijke Philips N.V. and are used under license.
This product has been manufactured by and is sold under the responsibility of Hongkong AquaShield Health Technology Company Limited and Hongkong AquaShield Health Technology Company Limited is the warrantor in relation to this product.
水護盾是飛利浦淨飲水解決方案、熱水解決方案、衛浴解決方案、水杯及個人按摩器唯一品牌官方授權運營主體。



3. 開機及切換溫度


開機及選擇溫度：在待機狀態下長按按摩器上的電源按鍵 2 秒，機器啟動模式 1；再次短按電源按鍵，切換到模式 2；再次短按電源按鍵，切換到模式 3，依次循環。

開啟按摩：當水溫達到指定溫度後，按摩功能自動開啟，30 分鐘後自動結束。




4. 關機

在任何工作狀態下，長按按摩器上的電源按鍵 2 秒，蜂鳴器長響 1.5 秒，結束當前模式進入待機狀態。





5. 使用遙控器

在待機狀態下，遙控器只有電源開關鍵有用。用遙控器對準按摩器內按  鍵，機器啟動模式 I。

在任何工作狀態下，用遙控器對準按摩器內按    鍵，機器進入相應的溫度。

在任何工作狀態下，用遙控器對準按摩器內按  鍵，可開啟或關閉按摩功能。


在任何工作狀態下，用遙控器對準桶內按  鍵，結束當前模式進入待機狀態。



遙控器

6. 收納按摩器

- (1) 將按摩器內水倒盡晾乾；
- (2) 把按摩器倒置於放有軟墊的地面上；
- (3) 雙手向下按壓按摩器底殼兩側，使其折疊；
- (4) 用手向內扳動支撐架，使其折疊靠近於底殼；
- (5) 正放按摩器，蓋上防塵蓋，遙控器放置到位，收納完成。



- ❗ 1. 建議不要加入超過 46°C 的水，以防燙傷腳部。為了您的安全，當水溫超過 50°C 時，設備停止加熱，伴隨 10 聲警示聲，同時指示燈紅色閃爍 10 次，然後進入關機狀態；水溫降低至 48°C 以下後，設備進入待機狀態。
2. 建議使用前後喝一杯 250ml 暖水。
3. 一般足浴 30-40 分鐘為宜，期間請適量飲用暖水。
4. 每部足浴按摩器在出廠前都經過嚴格的過水測試，若您收到的產品中有殘留的水漬，屬於正常現象，請放心使用。

PHILIPS

足部按摩器

足浴按摩器

PPM6501



Quick Start Guide
快速入門指南