


### 1. Installation


(1) If the support holders have been installed on the massager: unfold the support holders and place it on the ground, and remove the dust cover. While lifting the handle, press the massage turntable down until the massager unfolds normally.

(2) If the support holders are not installed on the massager: remove the dust cover and place the massager flat on the ground. While pressing one side of the massage turntable, lift the upper edge of the massager on the same side and lift it up to expand the massager to a certain angle; repeat the above on the other side to fully expand the massager. Then install the support holders according to the prompts on the massager.



### 2. Add water and power on


Place the massager on a flat surface, add an appropriate amount of water (it is recommended to add warm water at about 35°C to reduce waiting time), and connect to a 220-240V~/50-60Hz household power supply. After power on, the buzzer makes three beeps, the indicator light in the massager flashes slowly, and massager enters the standby state.



1


### 3. Turn on the device and switch levels

(1) In standby state, hold the power button for 2 seconds to start the massager in Level I (40°C); press the power button again to switch to Level II (43°C); and then press the power button again to switch to Level III (46°C). Press the button to cycle through the three levels in sequence. When the water temperature reaches the specified temperature, the massage function will automatically turn on, and end after 30 minutes.






### 4. Turn off the device


In any working mode, hold the power button for 2 seconds, the buzzer will sound for 1.5 seconds, and then end the current mode and enter the standby state.





### 5. Use the remote control

After power on, aim the remote control into the massager and press  button. The buzzer sounds once, the indicator light in the massager displays in green, and the massager turns on Level I;

In any working state, aim the remote control into the massager and press    button, and the massager will switch to the corresponding levels.

In any working state, aim the remote control into the massager and press  button to turn on / off the massage function;

In any working state, aim the remote control into the massager and press  button. The buzzer sounds for 1.5 seconds, and then end the current mode and enter the standby state.



2

### 6. Storage


(1) Pour out the water in the massager and let it dry;

(2) Place the massager upside down on the ground with a soft carpet;

(3) Press down on both sides of the massager bottom shell at the same time to fold it;

(4) Pull gently the support holders inward to fold it close to the bottom shell;

(5) Put the massager upwards with the dust cover, put the remote control in place, and the storage is complete.



**!** 1. It is recommended that do not add water exceeding 46°C to prevent scalding feet. For your safety, when the water temperature exceeds 50°C, the device stops heating, accompanied by 10 warning sounds, and the indicator light flashes red 10 times and then it enters shutdown state. After the water temperature drops below 48°C, the device enters standby mode.

2. It is recommended to drink a 250ml cup of warm water before and after use.

3. In general, the foot spa for 30 to 40 minutes is better. Please drink the appropriate amount of warm water during use.


4. Every Philips foot massager is qualified in strict water testing before delivery. It is normal for any residual water stains in the product that you receive. Please feel free to use it.

3

### 1. 安装按摩器


(1) 支撑架已装在机器上: 只需展开支撑架放于地面, 取下防尘盖, 一边提起提手, 一边向下按压按摩转盘, 直到正常展开。

(2) 支撑架没有装在机器上: 取下防尘盖, 按摩器平放于地面, 一边按住按摩转盘一侧, 一边提住按摩器同侧上沿往上提, 让按摩器展开一定角度; 换一侧重复上述动作, 把按摩器完全展开; 然后根据机器上的标示装上支撑架即可。



### 2. 加水通电

将机器平放, 加适量水 (建议加35°C左右温水, 以减少您等待时间), 通220-240V~/50-60Hz家用电源, 接通电源后, 蜂鸣器发出三声响声 (滴—滴—滴—), 按摩器内指示灯缓慢闪烁, 进入待机状态。



4



Visit us

[www.philips.com](http://www.philips.com)

There may be certain differences between the content of this manual and your product. Please refer to the actual product. We reserve the right to update the product at any time without prior notice.

© 2023 AquaShield  
All rights reserved

Philips and the Philips Shield Emblem are registered trademarks of Koninklijke Philips N.V. and are used under license.

This product has been manufactured by and is sold under the responsibility of Guangdong Deerma Technology Company Limited and Guangdong Deerma Technology Company Limited is the warrantor in relation to this product.

Made in China


Rev A SEP 23



### 3. 开机及切换档位:


开机及选择档位: 在待机状态下长按按摩器上的电源按键 2 秒, 机器启动 I 档; 再次短按电源按键, 切换到 II 档; 再次短按电源按键, 切换到 III 档, 依次往复循环。

开启按摩: 当水温达到指定温度后, 按摩功能自动开启, 30 分钟后自动结束。




### 4. 关机

在任何工作状态下, 长按按摩器上的电源按键 2 秒, 蜂鸣器长响 1.5 秒, 结束当前模式, 进入待机状态。





### 5. 使用遥控器

在待机状态下, 遥控器只有电源开关键有用。用遥控器对准按摩器内按  键, 机器启动 I 档。

在任何工作状态下, 用遥控器对准按摩器内按    键, 机器进入相应的档位。

在任何工作状态下, 用遥控器对准按摩器内按  键, 可开启或关闭按摩功能;


在任何工作状态下, 用遥控器对准桶内按  键, 结束当前模式进入待机状态。



遥控器

### 6. 收纳按摩器

- (1) 将按摩器内水倒尽晾干;
- (2) 把按摩器倒置于放有软垫的地面上;
- (3) 双手向下按压按摩器底壳两侧, 使其折叠;
- (4) 用手向内扳动支撑架, 使其折叠靠近于底壳;
- (5) 正放按摩器, 盖上防尘盖, 遥控器放置到位, 收纳完成。



- !** 1. 建议不要加入超过 46°C 的水, 以防烫伤脚部。为了您的安全, 当水温超过 50°C 时, 设备停止加热, 伴随 10 声警示音, 同时指示灯红色闪烁 10 次, 然后进入关机状态; 水温降低至 48°C 以下后, 设备进入待机状态。
2. 建议使用前后喝一杯 250ml 温水。
3. 一般足浴 30-40 分钟为宜, 期间请适量饮用温开水。
4. 每一台飞利浦足浴按摩器在出厂前都经过严格的过水测试, 若您收到的产品中有残留的水渍, 属于正常现象, 请放心使用。

PHILIPS

Foot Massager

Foot Spa Massager

PPM6501



Quick Start Guide