



Philips
Dial up Baby Monitor

SBCSC469

Calls your phone + regular baby monitor

Give yourself more freedom to move in and around the house and garden with the reassuring Dial-up monitor. The Dial-up monitor is a Baby Monitor, with the extra functionality of being connected to your phone when the baby is crying.

Reliability & Piece of mind

- Dial-in to listen and talk to your baby
- More transmission channels lowers the risk of interference
- The unit keeps on re-dialing if the line is busy
- PIN code prevents others dialing in to listen to your baby
- Low battery indication shows when to refresh batteries
- Analogue Pilot Tone minimises interference from other devices
- Digital System Check ensures the monitor is working reliably

Flexibility in monitoring your child

- Take the parent unit with you in and around the house
- Maximum operating distance between units with no obstacles

PHILIPS
sense and simplicity

Specifications

Tuner / Reception / Transmission

- Frequency band: 40.675 - 40.690 MHz
- Number of pilot tones: 16
- Pilot tone: Digital
- Maximum range: 200 m
- Number of channels: 4

Convenience

- Auto out of range warning
- Battery low indication
- Power on indication
- Volume control

Accessories

- AC/DC adaptor: 9V DC 200mA
- Batteries: 4 x AA baby unit not incl.
- Belt clip: Belt clip on parent unit
- User manual

Power

- Battery voltage: 4.8 V
- Operating time on battery: 12 hr

Product highlights

Dial-in to check on your baby

When you are in the garden, at the neighbour's or busy in a far corner of your home, you can call in to check on your baby or even speak a few words.

Number of channels

A choice of channels significantly reduces the risk of interference or sounds from other baby monitors in the neighbourhood.

Auto re-dial of phone number

Auto re-dial of phone number by baby unit when the line is busy until it gets connected.

Call back security code

When you use your baby monitor in Dialer mode your baby unit is connected to the public phone network. You have the possibility to dial-in to listen and talk to your child. For security and privacy reasons you need to enter a PIN code before you can listen in.

Low battery indication

To know in time when the batteries need to be recharged or replaced.

Digital Pilot Tone

A special tone that is transmitted along with the audio signal minimises the chance of interference from other wireless appliances.

Digital System check

A visible and audible warning is activated if the communication link between the baby unit and parent unit is unreliable.

Use in & around the house

Rest assured that as you take the parent unit with you as you move in and around your house, the parent unit will stay in touch with the baby unit. It keeps you reassuringly informed and able to respond quickly when baby calls.

Range in open air

In the open air with no obstacles, the safe distance between the baby unit and parent unit is greater than indoors, so you can take the parent unit with you into the garden or to the neighbour's house without losing contact.

Calls your phone

As both a regular wireless baby monitor and an innovative dial-up unit are in one, you're sure to hear your child wherever you are in and around the house or garden. It works both ways, the dialer calls you when your baby makes a sound and you can dial in to the baby unit to listen or speak a few comforting words to your child.

Charging base

Thanks to the built in battery charger in the base, you get extra freedom (when fully charged) to take the parent unit with you around the home and stay in touch with your baby. It's also a convenient place to store the parent unit, and ensure it's always ready for use.

LCD display on baby unit

LCD display on baby unit giving information on the working of the baby monitor system. Via icons on the LCD display you can check whether the mains and the public phone line are available. You can program the phone number you like to be called on when your baby makes a sound.

Volume control

A handy rotary control sets the volume to the ideal level to suit your preference.

Phone memory settings

In order not to have to insert the phone number where you want to be called on completely every time, you have the possibility to program 5 phone numbers.



Issue date 2007-08-07

Version: 1.0

12 NC: 9082 100 0371 1
EAN: 87 10895 85896 0

© 2007 Koninklijke Philips Electronics N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips Electronics N.V. or their respective owners.

www.philips.com