

Philips
Baby Cam

SBCSC490



Colour baby cam and baby monitor in one

Wireless colour baby cam and baby monitor in one

Watch & hear your baby

- See your baby on TV in full colour with baby cam
- Night vision to see your baby even in a dark room
- Record your baby during its early years on DVD or VCR

Reliability & Piece of mind

- More transmission channels lowers the risk of interference
- Digital System Check ensures the monitor is working reliably
- System check alarm Informs of malfunction or out of range
- System check light reassures you that the monitor is working
- Low battery indication shows when to refresh batteries

Convenience for you and your child

- Sound level lights display the level of your baby's sounds
- Simplifies the selection of the volume you prefer
- High quality microphone has adjustable sensitivity

Flexibility in monitoring your child

PHILIPS

Technical specifications

Tuner / Reception / Transmission

- **Frequency band:** 2.4GHz
- **Number of channels:** 4

Convenience

- Auto out of range warning
- Battery charging indication
- Battery full indication
- Battery low indication
- **System check:** Battery check light, System check alarm, System check light

Accessories

- **AC/DC adaptor:** 2x 12V DC 500 mA

- **Batteries:** 6 x AA baby unit not incl.
- **Cables:** RCA audio & video cable
- **Charger:** Docking base for parent unit
- **Extension cable:** RCA to SCART converter
- User manual
- **Battery pack:** NiMH pack parent unit incl.

Power

- **Charging time:** 12 hr
- **Operating time on battery:** 5 hr
- **Power supply:** AC/DC Adapter

Technical specifications

- **Operating temperature range:** 0 .. 40 °C

Product highlights

Colour baby cam

Natural looking, real life colour images of your baby are not just reassuring and natural but fun to look at or record as memories to treasure.

Night vision

When your baby's room gets darker, the camera automatically switches over to night vision so you can still see every reassuring detail without turning on the lights. In the dark you can't see colours so the video is transmitted as sharp black and white images.

Record baby on DVD+RW

To capture precious moments in your baby's natural development and keep them as treasured memories on a DVD recorder or VCR, simply use your Baby Cam like a video camera.

Number of channels

A choice of channels significantly reduces the risk of interference or sounds from other baby monitors in the neighbourhood.

Digital System check

A visible and audible warning is activated if the communication link between the baby unit and parent unit is unreliable.

System check alarm

The parent unit gives an audible alarm when it is outside the communication range of the baby unit or when the communication link is not reliable.

System check light

Green light on the parent unit lights when the connection between the baby and the parent unit is reliable and flashes when the parent unit is outside the range of the baby unit or when the communication link is not reliable.

Low battery indication

To know in time when the batteries need to be recharged or replaced.

Sound level lights

Sometimes it's a great help to 'see' when your baby makes a sound. This row of lights provide you with a clear visual indication.

Rechargeable parent unit

Putting the parent unit on the charging base will automatically start recharging of the batteries, so it's always ready for portable use.

Charging base

Thanks to the built in battery charger in the base, you get extra freedom (when fully charged) to take the parent unit with you around the home and stay in touch with your baby. It's also a convenient place to store the parent unit, and ensure it's always ready for use.

Volume control

A handy rotary control sets the volume to the ideal level to suit your preference.

Adjust microphone sensitivity

Possibility to set the sensitivity of the microphone so you only hear the sounds you want to hear.

Use in & around the house

Rest assured that as you take the parent unit with you as you move in and around your house, the parent unit will stay in touch with the baby unit. It keeps you reassuringly informed and able to respond quickly when baby calls.



Date of issue 2006-07-07

Version: 1.0

12 NC: 9082 100 01781
EAN: 87 10895 76087 4

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips Electronics N.V. or their respective owners.
© 2006 Koninklijke Philips Electronics N.V.
All Rights reserved.
www.philips.com