

PHILIPS

AVENT

Microwave Steam Steriliser



SCF271/01



Protect your baby, even when you travel

Simple, fast, portable

The Microwave Steriliser's compact design makes it ideal for travel. Despite its small size, it is the only microwave steriliser that fits 6 Philips AVENT bottles. Includes 2 AVENT Feeding Bottles and handy accessories.

Compact and lightweight

- Fits most microwaves. Convenient for travel.

Large capacity

- Holds 6 Philips AVENT bottles

Ultra fast, easy to use

- Just add water, load and place in the microwave

Safe easy handling

- Side grips close the lid securely

Safe, easy handling

- Contents remain sterile for up to 24 hours if unopened

Highlights

Natural steam sterilisation



Sterilising is all about protecting your baby from particularly harmful milk bacteria until his immune system is strong enough. The Philips Avent Steriliser uses the hospital method of steam sterilisation, which is quick, easy and efficient, with no chemicals involved.

Contents remain sterile



Contents remain sterile for up to 24 hours if unopened

Just add water



Just add water, load and place in the microwave for as little as 2 minutes. The exact length of the cycle will depend on the wattage of your microwave: 2 min at 1100-1850 Watt, 4 min at 850-1000 Watt, 6 min at 500-850 Watt.

Side grips close lid securely



The microwave steriliser has clips on the side for extra safety. The clips close the lid securely so hot water cannot easily escape when you take the steriliser out of the microwave. The side grips have also been designed to stay cooler to help you handle the steriliser safely.

Convenient for travel



The Philips Avent Microwave Steriliser has been designed to fit most microwaves on the market. Its small size makes it convenient for travel, ensuring that you always have a sterile bottle when you are going on a short overnight trip or on a longer holiday abroad. Also ideal as an extra steriliser for the grandparents' house.

Holds 6 Philips Avent bottles



Despite its small size, it is the only microwave steriliser that is designed to fit 6 Philips Avent bottles. Whereas most microwave sterilisers will only fit 4 bottles, the Philips Avent Microwave Steriliser allows you to sterilise a full day's worth of bottles in one go. It is also suitable for sterilising breast pumps.

Specifications

Technical specifications

Sterilisation Time: 2 min at 1100–1850 W, 4 min at 850–1000 W, 6 min at 500–800 W

Water capacity: 200 ml

Weight and dimensions

Weight: 740 g

Dimensions: 166 (H), 280 (W), 280 (L) mm

Country of origin

England

What is included

Tongs: 1 pcs

Newborn Soother: 1 pcs

Measuring jug: 1 pcs

Extra-soft newborn flow teat: 2 pcs

Extra Durable Feeding Bottle: 125 ml/4 oz, 260 ml/9 oz

Development stages

Stages: 0–6 months

