



Steriliser

- Bottle Steriliser and Dryer
- Premium

SCF293/01

Sterilise, dry and store

Sterilise and dry in 40 mins

Be ready for your baby's next feed in 40 minutes. Bottle Steriliser and Dryer Premium uses jets of filtered air to dry bottles before turning off. The steriliser is quick and hygienic, killing 99.9% of germs* for peace of mind at every feed.

Benefits

Kills 99.9% of germs*

- Say goodbye to harmful bacteria

Sterilise and dry in 40 mins

- A full sterilising and drying cycle lasts just 40 minutes

Integrated drip tray

- Designed to reduce the chance of unpleasant odours

Sterilise, dry and store

- Our steriliser lets you sterilise, dry and store
- Stays sterile for 24 hours*

Space-saving design

- Roomy inside, compact outside

Easy to clean and assemble

- This steriliser is quick and easy to clean

PHILIPS

Features

Kills 99.9% of germs*



Sterilising is gentle, effective and chemical-free with Philips Avent. Every steriliser uses the power of pure steam – nothing more, nothing less – to kill 99.9% of harmful germs*.

Sterilise and dry in 40 mins



It takes just 40 minutes to get bottles ready for your baby's next feed. After powerful steam-sterilising, a focused jet of filtered air dries bottles and accessories, making them ready for instant use.

Integrated drip tray



Our new drip tray protects the heating plate from milk droplets, reducing the chance of unpleasant odours.

Sterilise, dry and store



Our premium electric steriliser does more than clean bottles and kill germs – it dries and stores bottles and accessories, keeping them sterile for up to 24 hours.

Sterile for 24 hours*



The steriliser's thorough, chemical-free cleaning will keep its contents sterile for up to 24 hours. How? Just keep the lid on.

Space-saving design



Our steriliser is slender and yet still holds up to six Philips Avent baby bottles. It also fits all the other essentials, from teats and soothers to a manual breast pump.

Easy to clean and assemble



Top to bottom, inside and out, the steriliser is quick and easy to clean – even the heating plate. So you get more time to be with your little one.

Specifications

Please note that this is a pre-sales leaflet. The contents of this leaflet reflect the best of our knowledge per date and country mentioned above. The contents of this leaflet are subject to change without notice. Philips does not accept any liability as to the contents of this leaflet.

Weight and dimensions

Dimensions	304 x 191 x 378 mm
Weight	2.4 kg

Country of origin

Made in	China
---------	-------

What is included

Electric steam steriliser	1 pcs
Tongs	1 pcs

Development stages

Stage	0–6 months
-------	------------

Compatibility

Philips Avent range-compatible	Yes
--------------------------------	-----

Design specifications

Materials	Plastic (PP)
-----------	--------------

Technical specifications

Power consumption	650 W
-------------------	-------

Voltage

220-240 V~ 50-60 Hz, 220 V~ 60 Hz
(Korea), 120-127 V~ 60 Hz (NAM),
110 V~ 60 Hz (Taiwan)

Safety Classification

Class 1

* Escherichia coli, Pseudomonas aeruginosa, Staphylococcus aureas, Streptococcus agalactiae, Cronobacter sakazakii, Salmonella enterica, Listeria monocytogenes. The test results are provided by an independent test lab.



data subject to change
2020, December 22

Version: 2.0.1
EAN:

© 2020 Koninklijke Philips N.V.
All rights reserved.

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips N.V. or their respective owners.

www.philips.com