

PHILIPS

AVENT

3-in-1 electric steam sterilizer

Kills 99.9% of harmful germs

Sterilizes in 6 minutes

Fits 6 Philips Avent bottles

Adjustable 3-in-1 design

SCF288/05



Convenient and effective sterilization

Flexible, easy loading

With its adjustable size, the Philips Avent 3-in-1 electric steam sterilizer takes up the least amount of kitchen space yet perfectly fits the items you want to sterilize whether it's a few small items or a full load.

Space-saving 3-in-1 design

- 3-in-1 modular sterilizer design

Effective sterilizing using natural steam

- Natural steam sterilizing kills 99.9% of harmful germs
- Sterile for up to 24 hours if the lid is unopened
- Fast cycle and auto shut off function

Fits various bottle types and other products

- Spacious design
- Sterilizes various bottles, baby products & accessories

Easy to clean and safe sterilizing

- Easy to clean and safe sterilizing

Highlights

Flexible 3-in-1 sterilizer



The sterilizer's unique modular design enables you to fit the bottles and accessories flexibly, and organize them easily. Thus loading and unloading are very convenient. It also takes up minimal kitchen space.

Natural steam sterilizing



The sterilizer uses natural steam to sterilize baby bottles and other products, killing 99.9% of harmful germs without using chemicals. Perfect for giving you peace of mind that all your baby bottles and other products are sterile.

Fast sterilization



The sterilizing cycle lasts just 6 minutes. After this time, the sterilizer automatically shuts off, giving you extra speed and safety.

Spacious design



Holds up to six 330 ml / 11oz Philips Avent Classic and Natural bottles to be sterilized at once.

Open design



With our open design you can easily keep the heating plate clean, allowing you to sterilize with clean steam every time.

Sterile for up to 24 hours



The sterilizer will keep its contents (baby bottles, soothers etc.) sterile for up to 24 hours if the lid is unopened.

Works across bottle types

The sterilizer is suitable for use with both standard neck and wide neck baby bottles. It also fits other baby products and accessories.

Specifications

Country of origin

Made in: Turkey

What is included

Tongs: 1 pcs

Power

Voltage: 110 V

Development stages

Stage: 0 - 6 months

Material

Polypropylene

Weight and dimensions

Dimensions: 290 x 160 x 150 (w x d x h) mm

Weight: 1.5 kg

Compatibility

Philips-Avent range compatible

Technical specifications

Power consumption: 650 W

Voltage: 120V~60Hz

Safety Classification: Class 1

Bazaarvoice_Family_MCC

Bottle_warmers_and_sterilizers:

SCF288_3_in_1_Sterilizers

