

PHILIPS

AVENT

Microwave Steam
Steriliser

SCF271/06



Ultra fast and convenient

Sterilises 6 bottles in 2 minutes*

Philips Avent Microwave Steam Steriliser's lightweight, compact design makes it ideal for use in and out of the home. Contents remain sterile for up to 24 hours if lid is unopened.

Ultra fast, easy to use

- Just add water, load and place in the microwave

Compact and lightweight

- Convenient for travel. Fits most microwaves.

Safe, easy handling

- Contents remain sterile for up to 24 hours if unopened

Safe easy handling

- Side grips close the lid securely

Large capacity

- Holds six Philips Avent bottles

Highlights

Natural steam sterilisation

Sterilising is all about protecting your baby from particularly harmful milk bacteria until his immune system is strong enough. The Philips Avent Steriliser uses the hospital method of steam sterilisation, which is quick, easy and efficient, with no chemicals involved.

Clips close the lid securely



The microwave steriliser has clips on the side for extra safety. The clips close the lid securely so hot water cannot easily escape when you take the steriliser out of the microwave. The side grips have also been designed to stay cooler to help you handle the steriliser safely.

Contents remain sterile



Contents remain sterile for up to 24 hours if unopened

Convenient for travel



The Philips Avent Microwave Steriliser has been designed to fit most microwaves on the market. Its small size makes it convenient for

travel, ensuring that you always have a sterile bottle when you are going on a short overnight trip or on a longer holiday abroad. Also ideal as an extra steriliser for at the grandparents' house. Dimensions: 166 (H), 280 (W), 280 (L) mm.

Holds 6 Philips Avent bottles



Despite its small size, it is the only microwave steriliser that is designed to fit 6 Philips Avent bottles. Whereas most microwave sterilisers will only fit 4 bottles, the Philips Avent Microwave Steriliser allows you to sterilise a full day's worth of bottles in one go. It is also suitable for sterilising breast pumps.

Just add water



Just add water, load and place in the microwave for as little as 2 minutes. The exact length of the cycle will depend on the wattage of your microwave: 2 min at 1100-1850 Watt, 4 min at 850-1000 Watt, 6 min at 500-850 Watt.

Specifications

Country of origin

England

Development stages

Stage: 0-6 months

What is included

Extra soft Newborn Flow teat: 1 pcs

Extra soft Slow Flow teat: 1 pcs

Weight and dimensions

Dimensions: 166 (H), 280 (W), 280 (L) mm

Weight: 740 g

What is included

Microwave steam steriliser: 1 pcs

Tongs: 1 pcs

Feeding Bottle (260 ml/9 oz): 1 pcs

Feeding Bottle (125 ml/4 oz): 1 pcs

Newborn Soother: 1 pcs

