

PHILIPS

Dial-up Baby Monitor

SBCSC469



The baby monitor that calls your phone

Give yourself more freedom to move in and around the house and garden with the reassuring Dial-up monitor. The Dial-up monitor is a baby monitor that calls your phone when the baby is crying.

Comforting for your baby

- Soft, reassuring night light to comfort your baby

Convenience for you and your child

- Charging base keeps batteries charged and ready for use
- LCD display on baby unit shows phone number
- Simplifies the selection of the volume you prefer
- 5 phone memory settings to programme for numbers
- You choose the phone number the baby unit calls
- Sound-level lights display the level of your baby's sounds
- High-quality microphone has adjustable sensitivity
- Save money with rechargeable parent unit and charging base

Flexibility in monitoring your child

Grows with your baby

Reliability and peace of mind

Highlights

Dial in to check on your baby

When you are in the garden, at the neighbour's or busy in a far corner of your home, you can call in to check on your baby or even speak a few words.

Number of channels

A choice of channels significantly reduces the risk of interference or sounds from other baby monitors in the neighbourhood.

Auto redial of phone number

Auto redial of phone number by baby unit when the line is busy until it gets connected.

Call back security code

When you use your baby monitor in Dialler mode, your baby unit is connected to the public phone network. You can dial in to listen and talk to your child. For security and privacy reasons you need to enter a PIN code before you can listen in.

Low battery indication

To promptly be aware when the batteries need to be recharged or replaced.

Digital Pilot Tone

A special tone that is transmitted along with the audio signal to minimise the chance of interference from other wireless appliances.

Digital System Check



Dynamic Contrast
100000:1

A visible and audible warning is activated if the communication link between the baby unit and parent unit is unreliable.

Use in and around the house

Rest assured that as you take the parent unit with you as you move in and around your house, the parent unit will stay in touch with the baby unit. It keeps you reassuringly informed and able to respond quickly when baby calls.

Range in open air

In the open air with no obstacles, the safe distance between the baby unit and parent unit is greater than indoors, so you can take the parent unit with you into the garden or to the neighbour's house without losing contact.

Calls your phone

With both a standard wireless baby monitor and an innovative dial-up unit in one, you're sure to hear your child wherever you are in and around the house or garden. It works both ways: the dialler calls you when your baby makes a sound and you can dial in to the baby unit to listen or speak a few comforting words to your child.

Charging base

Thanks to the built-in battery charger in the base, you get extra freedom (when fully charged) to take the parent unit with you around the home and stay in touch with your baby. It's also a convenient place to store the parent unit and ensure it's always ready for use.

LCD display on baby unit

LCD display on baby unit giving information on the operation of the baby monitor system. Via icons on the LCD display, you can check whether the mains and the public phone line are available. You can programme the phone number you want to be called on when your baby makes a sound.

Volume control

A handy rotary control sets the volume to the ideal level to suit your preference.

Phone memory settings

In order not to have to enter the full phone number on which you want to be called every time, you have the option to programme 5 phone numbers.

Programme phone number

You are called on this number when your baby makes a sound.

Sound-level lights

Sometimes it's a great help to 'see' when your baby makes a sound. This row of lights provides you with a clear visual indication.

Adjust microphone sensitivity

Possibility to set the sensitivity of the microphone so you only hear the sounds you want to hear.

Rechargeable parent unit

Putting the parent unit on the charging base will automatically start the batteries recharging, so it's always ready for portable use.

Night light

A soft, glowing light is reassuring and provides a focal point in the dark.

Specifications

Tuner/Reception/Transmission

Frequency band: 40.675 - 40.690 MHz

Maximum range: 200 m

Number of channels: 4

Number of pilot tones: 16

Pilot tone: Digital

Convenience

Power on indication

Battery low indication

Auto out-of-range warning

Volume control

Power

Battery voltage: 4.8 V

Accessories

AC/DC Adapter: 9 V DC 200 mA

Belt clip: Belt clip on parent unit

Batteries: 4 x AA baby unit not incl.

User Manual

Power

Operating time on battery: 12 hour(s)

