

**PHILIPS**

 Product Picture

**AVENT**

Microwave Sterilizer  
Starter Set

Classic

SCF277/01

# Sterilizes 6 bottles in 2 minutes\*

Ultra fast sterilizer, easy to use

Avent Microwave Sterilizer Starter Set is compact and lightweight, ideal for home and travel

**Ultra fast, easy to use**

- Just add water, load and place in the microwave

**Compact and lightweight**

- Convenient for travel. Fits most microwaves.

**Safe, easy handling**

- Contents remain sterile for up to 24 hours if unopened

**Safe easy handling**

- Side grips close the lid securely

**Large capacity**

- Holds six Philips Avent bottles

# Highlights

## Just add water



Just add water, load and place in the microwave for as little as 2 minutes. The exact length of the cycle will depend on the wattage of your microwave: 2 min at 1100–1850 Watt, 4 min at 850–1000 Watt, 6 min at 500–850 Watt.

## Convenient for travel



The Philips Avent Microwave Sterilizer has been designed to fit most microwaves in the market. Its small size makes it convenient for travel, ensuring that you always have a sterile bottle when you are going on a short overnight trip or on a longer holiday abroad. Also ideal as an extra sterilizer for the grandparents' house. Dimensions: 166 (H), 280 (W), 280 (L) mm.

## Contents remain sterile



Contents remain sterile for up to 24 hours if unopened

## Natural steam sterilization

Sterilizing is all about protecting your baby from particularly harmful milk bacteria until his immune system is strong enough. The Philips Avent Sterilizer uses the hospital method of steam sterilization, which is quick, easy, and efficient, with no chemicals involved.

## Clips close the lid securely



The microwave sterilizer has clips on the side for extra safety. The clips close the lid securely so hot water cannot easily escape when you take the sterilizer out of the microwave. The side grips have also been designed to stay cooler to help you handle the sterilizer safely.

## Holds 6 Philips Avent bottles



Despite its small size, it is the only microwave sterilizer that is designed to fit 6 Philips Avent bottles. Whereas most microwave sterilizers will only fit 4 bottles, the Philips Avent Microwave Sterilizer allows you to sterilize a full day's worth of bottles in one go. It is also suitable for sterilizing breast pumps.

# Specifications

## Technical specifications

**Water capacity:** 200ml

**Sterilization Time:** 2 min at 1100–1850W, 4 min at 850–1000W, 6 min at 500–800W

## Weight and dimensions

**Weight:** 740 g

**Dimensions:** 166 (H), 280 (W), 280 (L) mm

## Country of origin

England

## What is included

**Microwave steam sterilizer:** 1 pcs

**Tongs:** 1 pcs

**Classic Bottle 4oz:** 2 pcs

**Measuring jug:** 1 pcs

**Classic Bottle 9oz:** 2 pcs

## Development stages

**Stage:** 0 – 6 months

