


PHILIPS

AVENT

DECT baby monitor

 Product Picture

SCD530/00

PHILIPS
AVENT

PHILIPS
AVENT

Healthy climate, total comfort

Zero interference guaranteed with DECT technology

Enjoy complete peace of mind with the new Philips Avent range of DECT Baby Monitors you can relax, safe in the knowledge your baby's happy even when you are out the room.

Zero interference

- DECT technology guarantees zero interference

Crystal clear sound

- LEDs light to signal noise levels
- Choose the best sound level for your surroundings
- Reassurance with crystal clear sound

330 m range

- Up to 24 hour operation time before recharge
- Always know that you are connected
- Extra long range for total mobility

Complete comfort

- Stay connected with talk back
- Remote activated night light and lullabies
- Monitor the humidity & temperature in the baby's room

Highlights

Guaranteed zero interference

DECT technology guarantees zero interference from any other transmitting product like other baby monitors, cordless phones and cell phones. Data encryption provides a secure and private connection, so you can be sure that you are the only one that can hear your baby

Reassuring crystal clear sound

Hear every tiny giggle, gurgle and hic-up with perfect clarity. DECT technology provides high quality, crystal clear sound so you can hear your baby anytime

Superior operating time

The small, rechargeable parent unit will give you the freedom of cordless roaming for up to 24 hours before re-charging is required

Humidity & temperature sensor

Combined humidity and temperature sensor allows you to monitor the climate in baby's room. Your baby can't regulate its body temperature as well as you can and a slight change in temperature, and too much or too little humidity can make your baby restless. A specially combined humidity and temperature sensor will immediately alert you, through the digital display on the parent unit, if the climate in your baby's room changes. Monitor the complete climate in baby's room

LEDs light to signal noise

Lights are activated to indicate the level of sound in your baby's room. Even with the Parent Unit is muted, a vibrating sound alert will notify you when a set sound level is reached

Extended operating range

With a range of 330m, a belt clip and neck cord so you can be fully mobile in and around the home. A versatile travel bag will protect your baby monitor when you are away from home

Adjustable sound sensitivity

Enables you to adjust the sound and volume levels, so you can hear every giggle, gurgle and hic-up

Out of range/low power signals

The parent unit of the Philips Avent baby monitor will alert when the power is low, or if you are out of range

Lullabies and night light

Your baby may still be restless when you first put them to bed. Help soothe and calm your baby to sleep with the warm tranquil glow of the night light which can be activate from the parent or baby unit. (Remote activation not available in US) There's nothing like a gentle lullaby to calm a restless baby. From any room in the house you can select one of 5 relaxing tunes, helping your baby to drift effortlessly to sleep in no time. (Remote activation not available in US)

Two way communication

Sometimes all your baby needs is the soothing sound of your voice. With one click of this essential feature you can connect with your baby from anywhere around the home

Specifications

Development stages

Stage: Pregnancy, 0 - 6 months

Power

Operating time on battery: 24 hour(s)

Power supply: 220 - 240 V

Charging time: 3 hour(s)

Tuner/Reception/Transmission

Automatic channel selection

Number of channels: 120

Convenience

Power on indication

Auto out-of-range warning

Battery low indication

Battery charging indication

Volume control

Sound-level lights

Technical specifications

Operating temperature range: 10 - 40 °C

Power

Power supply: 120 V (US)

Tuner/Reception/Transmission

Frequency band: DECT

Accessories

Batteries

Charging base for parent unit

Quick start guide

Convenience

Sensitivity control

Accessories

Belt clip, neck cord and travel bag

AC/DC adaptor

DFU/ user manual

Logistic data

F-box dimensions (W x H x D): 305 x 135 x 187 mm

Convenience

Vibration alert

Technical specifications

Storage temperature range: 10 - 40 °C

