

# PHILIPS

## Dial up Baby Monitor

SBCSC469



## Calls your phone + regular baby monitor

Give yourself more freedom to move in and around the house and garden with the reassuring Dial-up monitor. The Dial-up monitor is a Baby Monitor, with the extra functionality of being connected to your phone when the baby is crying.

### Comforting your baby

- Soft, reassuring night light to comfort your baby

### Convenience for you and your child

- Charging Base keeps batteries recharged and ready for use
- LCD display on baby unit shows phone number
- Simplifies the selection of the volume you prefer
- 5 phone memory settings to program for numbers
- You choose the phone number the baby unit calls
- Sound-level lights display the level of your baby's sounds
- High-quality microphone has adjustable sensitivity
- Save money with rechargeable parent unit and charging base

### Flexibility in monitoring your child

### Growths with your baby

### Reliability & Piece of mind

# Highlights

## Dial-in to check on your baby

When you are in the garden, at the neighbour's or busy in a far corner of your home, you can call in to check on your baby or even speak a few words.

## Number of channels

A choice of channels significantly reduces the risk of interference or sounds from other baby monitors in the neighbourhood.

## Auto re-dial of phone number

Auto re-dial of phone number by baby unit when the line is busy until it gets connected.

## Call back security code

When you use your baby monitor in Dialer mode your baby unit is connected to the public phone network. You have the possibility to dial-in to listen and talk to your child. For security and privacy reasons you need to enter a PIN code before you can listen in.

## Battery-low indication

To know in time when the batteries need to be recharged or replaced.

## Digital Pilot Tone

A special tone that is transmitted along with the audio signal to minimize the chance of interference from other wireless appliances.

## Digital System check



**Dynamic Contrast**  
**100000:1**

A visible and audible warning is activated if the communication link between the baby unit and parent unit is unreliable.

## Use in & around the house

Rest assured that as you take the parent unit with you as you move in and around your house, the parent unit will stay in touch with the baby unit. It keeps you reassuringly informed and able to respond quickly when baby calls.

## Range in open air

In the open air with no obstacles, the safe distance between the baby unit and parent unit is greater than indoors, so you can take the parent unit with you into the garden or to the neighbour's house without losing contact.

## Calls your phone

As both a regular wireless baby monitor and an innovative dial-up unit are in one, you're sure to hear your child wherever you are in and around the house or garden. It works both ways, the dialer calls you when your baby makes a sound and you can dial in to the baby unit to listen or speak a few comforting words to your child.

## Charging base

Thanks to the built-in battery charger in the base, you get extra freedom (when fully charged) to take the parent unit with you around the home and stay in touch with your baby. It's also a convenient place to store the parent unit, and ensure it's always ready for use.

## LCD display on baby unit

LCD display on baby unit giving information on the working of the baby monitor system. Via icons on the LCD display you can check whether the mains and the public phone line are available. You can program the phone number you like to be called on when your baby makes a sound.

## Volume control

A handy rotary control sets the volume to the ideal level to suit your preference.

## Phone memory settings

In order not to have to insert the phone number where you want to be called on completely every time, you have the possibility to program 5 phone numbers.

## Program phone number

You are called on this number when your baby makes a sound.

## Sound-level lights

Sometimes it's a great help to 'see' when your baby makes a sound. This row of lights provide you with a clear visual indication.

## Adjust Microphone sensitivity

Possibility to set the sensitivity of the microphone so you only hear the sounds you want to hear.

## Rechargeable Parent unit

Putting the parent unit on the charging base will automatically start recharging of the batteries, so it's always ready for portable use.

## Night light

A soft, glowing light is reassuring and provides a focal point in the dark.

# Specifications

## **Tuner/Reception/Transmission**

Frequency band: 40.675 - 40.690 MHz

Maximum range: 200 m

Number of channels: 4

Number of pilot tones: 16

Pilot tone: Digital

## **Convenience**

Auto out-of-range warning

Battery low indication

Power on indication

Volume control

## **Power**

Battery voltage: 4.8 V

## **Accessories**

Belt clip: Belt clip on parent unit

AC/DC Adaptor: 9V DC 200mA

Batteries: 4 x AA baby unit not incl.

User Manual

## **Power**

Operating time on battery: 12 hour(s)

