

Philips
Nutrition starter pack



SCF230/00

Everything you need to prepare your baby's food

all bottles and jars are sterile and safe now

Everything you need to quickly and confidently prepare your baby's food, with the added assurance that all bottles and jars are sterile and safe.

Quick and easy food preparation

- Click-step temperature setting
- Bottle and jar lifter
- Fits all bottle and jar types

Baby's food never too hot

- The baby's food never gets too hot
- Temperature control system
- Safe cool wall due to double insulation
- Graduated temperature control

Fast and reliable sterilizing

- Convenient sterilizer for use in your microwave oven
- Sterilizes up to 6 regular bottles and 4 wide-neck bottles
- No chemicals needed
- Kills all household bacteria in minutes using tap water

PHILIPS

Specifications

Convenience

- Power on indication

Technical specifications

- Heating time: 8-10 minute(s)
- Safety classification: Class 2

Convenience

- Automatic shut-off

- Fits all bottles: All baby bottles & jar types
- Ready indicator

Power

- Bottle warmer: 220/240 V

Technical specifications

- Sterilizing time: 8-12 minute(s)

Highlights

Temperature control system

The latest heating technology incorporates a PTC heating element and two sensors ensures the water in the beaker quickly reaches the ideal temperature and maintains it at a safe level that won't burn your baby's mouth with food or milk that is too hot.

Overheat protection

To avoid the danger of accidentally burning your baby's mouth, the automatic switch off ensures the food does not get too hot.

PTC heating element

To avoid the danger of accidentally burning your baby's mouth, the automatic switch off ensures the food does not get too hot.

Double insulation

With your safety and convenience in mind, the double insulated bottle warmer is designed to be used in every room in the house, not just where a earthed mains socket is available. There are no exposed metal parts that can become live.

Microwave sterilizing

By heating the water in the container to above 95 degrees in a microwave oven, you will ensure that harmful bacteria and germs are safely destroyed.

Disinfects completely

Protect your newborn baby from any harmful household bacteria or germs by disinfecting her bottles, teats, pacifiers and small plastic toys.

Holds 4-6 bottles

Convenient use of the sterilizer means having the disinfected bottles ready when you need them. This means fitting all bottles needed for a day's feeding into the sterilizer in one go.

No chemicals needed

Chemical residues in baby's food are a nightmare to think about. Therefore, sterilization is done by using very hot steam.

Bottle and jar lifter

Even short bottles and jars are easily removed from the bottle warmer thanks to the handy lifting handle.

Click-step temperature setting

With the Click-step temperature setting you can adjust the setting to suit the different types of food and bottles and jars you want to heat up.

Fits all bottle and jar types

The product is designed in such a way that all kind of sizes and shapes of bottles and jars fit in.



Issue date 2021-02-15

Version: 3.0.1

© 2021 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com