

# PHILIPS

Baby bottle warmer

SCF215/86

 Product Picture

## For home and car use

special car adapter included

The correct temperature of your baby's milk and food is very important for the baby's health and well-being.

### **For use at home and away**

- Car adapter

### **Quick and easy food preparation**

- Click-step temperature setting
- Bottle and jar lifter
- Fits all bottle and jar types

### **Baby's food never too hot**

- The baby's food never gets too hot
- Temperature control system
- Safe cool wall due to double insulation
- Graduated temperature control

# Highlights

## Car adapter

A bottle warmer with car adapter that can heat baby's food in the car. This way you can maintain the feeding cycle and routine of your baby even while traveling.

## Temperature control system

The latest heating technology incorporates a PTC heating element and two sensors ensures the water in the beaker quickly reaches the ideal temperature and maintains it at a safe level that won't burn your baby's mouth with food or milk that is too hot.

## Overheat protection

To avoid the danger of accidentally burning your baby's mouth, the automatic switch off ensures the food does not get too hot.

## PTC heating element

To avoid the danger of accidentally burning your baby's mouth, the automatic switch off ensures the food does not get too hot.

## Double insulation

With your safety and convenience in mind, the double insulated bottle warmer is designed to be used in every room in the house, not just where a earthed mains socket is available. There are no exposed metal parts that can become live.

## Bottle and jar lifter

Even short bottles and jars are easily removed from the bottle warmer thanks to the handy lifting handle.

## Click-step temperature setting

With the Click-step temperature setting you can adjust the setting to suit the different types of food and bottles and jars you want to heat up.

## Fits all bottle and jar types

The product is designed in such a way that all kind of sizes and shapes of bottles and jars fit in.

# Specifications

## Power

**Mains power:** 220-240, car adapter 12 V

**Power consumption:** 80/90 W

## Convenience

Power on indication

## Accessories

User manual

## Technical specifications

**Heating time:** 8-15 (home-car) minute(s)

**Safety classification:** Class 2

## Convenience

Automatic shut-off

**Fits all bottles:** All baby bottles & jar types

Ready indicator

