

# PHILIPS

## AVENT

DECT baby monitor

SCD499/00

 Product Picture

## Guaranteed zero interference

### With DECT digital technology

This digital technology provides a secured, private connection, because you want to be the only one listening to your baby. Automatically chooses an unused channel and switches as it detects another device using the same channel.

#### **Complete peace of mind**

- Indicates a continuous connection between the two units
- Uses lights to indicate if the baby makes noise
- Guarantees zero interference from any other device
- Remotely monitor the baby's room temperature

#### **Ultimate mobility in and around the house**

- Belt clip and neck cord for hands-free convenience
- Small, mobile parent unit to freely roam around the house
- Rechargeable parent unit for minimum 24 hours of monitoring
- 300 m range ensures secure reception in and around the house
- Travel pouch for easy storage

#### **Soothing sights, sounds and words**

- Comforts the baby in the dark with soothing stars
- Five lullabies soothe baby to sleep
- Provides the ability to allow you to talk to the baby

# Highlights

## Room temperature thermometer

Remotely monitor the baby's room temperature for extra comfort and control.

## Guaranteed zero interference

Guarantees zero interference from any other device (other baby monitors, cordless phones and cell phones). Provides a secure and private connection using data encryption. You will be the only one who can hear your baby and you only hear your own baby.

## Digital signal confirmation

Indicates a continuous connection between the baby and the parent unit with visible and audible link indicators.

## Sound level lights

Uses lights to indicate if the baby makes noise, even with volume off.

## Travel pouch

Travel pouch for easy storage while traveling.

## Belt clip and neck cord

The belt clip and neck cord provide hands-free convenience and mobility: clip the parent unit to your belt or wear it around your neck.

## Rechargeable parent unit



The rechargeable parent unit gives you a minimum of 24 hours of cordless monitoring with a range of up to 300 m (900 feet).

## Small, mobile parent unit

Allows you to freely roam around the house due to the small size, but still hear when your baby needs you.

## With a range up to 300 m

With a range up to 300 m you are ensured a secure reception in and around the house.

## Five lullabies

Five lullabies soothe baby to sleep.

## Starry night-light

Nightlight with soothing stars to comfort your baby.

## Parent talkback

Provides the ability to allow you to hear the baby and talk to the baby.

# Specifications

## Development stages

Stage: 0 – 6 months, 6 – 12 months

## Power

Operating time on battery: 24 hour(s)

Power supply: 230–240 V

Charging time: 8 hour(s)

## Tuner/Reception/Transmission

Automatic channel selection

Number of channels: 120

## Convenience

Power on indication

Battery low indication

Auto out-of-range warning

Battery charging indication

Volume control

Night light

Sound-level lights

System check: Battery check light, System check alarm, System check light

## Technical specifications

Operating temperature range: 0 .. 40 °C

## Power

Rechargeable

## Tuner/Reception/Transmission

Frequency band: DECT

## Accessories

Belt clip

Batteries: 2 x AAA NiMH rechargeable

Charger: Charging base for parent unit

Quick start guide

## Accessories

AC/DC adaptor: 2x 9VDC, 300mA

DFU/ user manual: Dutch, English, Finnish, French, German, Greek, Italian, Portuguese, Spanish, Swedish, Norwegian, Danish

## Technical specifications

Storage temperature range: -20 .. +60 °C

## Logistic data

F-box dimensions (W x H x D):

305x187x135 mm

