

Philips
DECT baby monitor



SCD489/00

Guaranteed zero interference

With DECT digital technology

Enjoy complete reassurance. With DECT digital technology, you are guaranteed a secure, zero interference connection between you and your baby. For extra peace of mind, monitor your baby's room temperature from your parent unit.

Complete peace of mind

- Indicates a continuous connection between the two units
- Uses lights to indicate if the baby makes noise
- Rechargeable parent unit for minimum 24 hours of monitoring
- Provides the ability to allow you to talk back to the baby
- Guarantees zero interference from any other device
- Remotely monitor the baby's room temperature

Ultimate mobility in and around the house

- Small, mobile parent unit to freely roam around the house
- 300 m range ensures secure reception in and around the house
- The neck cord provides hands-free convenience and mobility
- Travel pouch for easy storage

Soothing words

- Comforts the baby in the dark with soothing stars
- Five lullabies soothe baby to sleep

PHILIPS

Highlights

Room temperature thermometer

Remotely monitor the baby's room temperature for extra comfort and control.

Guaranteed zero interference



Guarantees zero interference from any other device (other baby monitors, cordless phones and cell phones). Provides a secure and private connection using data encryption. You will be the only one who can hear your baby and you only hear your own baby.

Rechargeable parent unit



The rechargeable parent unit gives you a minimum of 24 hours of cordless monitoring with a range of up to 300 m (900 feet).

Digital signal confirmation



Indicates a continuous connection between the baby and the parent unit with visible and audible link indicators.

Talk-back

Provides the ability to allow you to talk back to the baby.

Sound level lights

Uses lights to indicate if the baby makes noise, even with volume off.

Travel pouch

Travel pouch for easy storage while traveling.

Neck cord

The neck cord provides hands-free convenience and mobility: clip the parent unit to your belt or wear it around your neck.

Small, mobile parent unit



Allows you to freely roam around the house due to the small size, but still hear when your baby needs you.

With a range up to 300 m

With a range up to 300 m you are ensured a secure reception in and around the house.

Starry night-light

Nightlight with soothing stars to comfort your baby.

Five lullabies

Five lullabies soothe baby to sleep.

Specifications

Power

- Power supply: AC/DC Adapter
- Operating time on battery: 12 hour(s)
- Charging time: 16 hour(s)

Tuner/Reception/Transmission

- Automatic channel selection
- Number of channels: 120

Convenience

- Power on indication
- Auto out-of-range warning
- Battery low indication
- Battery charging indication
- Night light
- Volume control
- Sound-level lights
- System check: Battery check light, System check alarm, System check light

Technical specifications

- Operating temperature range: 0 .. 40 °C

Power

- Rechargeable: No

Tuner/Reception/Transmission

- Frequency band: DECT

Accessories

- Belt clip
- Batteries: 2 x AAA NiMH rechargeable
- Charger: Charging base for parent unit

Accessories

- AC/DC adaptor: 2x 9VDC, 300mA
- DFU/ user manual: Danish/Norwegian, Dutch, English, Finnish, French, German, Greek, Italian, Portuguese, Spanish, Swedish

Technical specifications

- Storage temperature range: -20 .. +60 °C



Issue date 2021-02-15

Version: 7.0.1

© 2021 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com