

PHILIPS

AVENT

Smart baby monitor

For smartphone and tablet

Compatible with iOS & Android



Product Picture

SCD860



Connecting you to your baby anytime, anywhere

The Smart baby monitor enables you and your beloved ones to watch over your little one, from wherever you are. The App allows you to switch between networks and optimize audio & video quality for the best connection to your baby

Personalized to your needs

- Multi-color nightlight to soothe your baby to sleep
- Personalize settings, monitor the way you want
- A selection of lullabies for calm, contented sleep
- Reassuring TalkBack function

A secure and private connection

- Supports multiple cameras/viewers, invite your beloved ones
- Monitoring performance dependent upon Wi-Fi connection
- Simply use the QR code to set up and download the app
- Up to 720p HD day & night vision quality

Highlights

Secure and private connection

The connection is completely secure and private. You can invite your beloved ones to watch-in, from wherever you or they are, up to 10 accounts in total. The app supports up to 10 cameras, with 3 simultaneous viewers per camera.

Wi-Fi connectivity

Both, the monitor & app need to be connected to the internet. The monitor connects to the internet via Wi-Fi, which makes the performance of the monitor directly dependent upon the performance of your Wi-Fi connection. Please make sure the Philips Avent Smart baby monitor is located in close range of the Wi-Fi router, or use Wi-Fi repeater / powerline adapter with integrated Wi-Fi to boost the Wi-Fi signal near the monitor. Your smart device can be connected to the internet either via 3G, 4G or Wi-Fi, enabling you to watch over your little one from wherever you are.

Personalized to your needs

You can set the product features how and when you would like to. Whether it for instance is the color of the nightlight, or a specific lullaby.

Easy set up

The Philips Avent Smart baby monitor is incredibly easy to set up. Simply download the app and use the in-app QR code to connect the camera to your local Wi-Fi network. The

app includes a first time user guide, which will support you and explain the buttons and features of the app.

Day & night vision

See and hear your baby during the day & night. The camera offers superior video and audio quality, with up to 720p HD day & night vision. Full color by day and infra red black and white by night.

Soothing lullabies

Help soothe your baby off to sleep by playing one of the 10 soothing lullabies. Start the lullabies directly via the camera in your baby's room, or operate it remotely via the app. You can choose which songs to play at what moment.

Multi-color nightlight

Use the multi-color nightlight to create a gentle calming ambience that will send your baby to sleep. Start the nightlight directly via the camera in your baby's room, or operate it remotely via the app. You can specify the color of the light and set a timer to decide when to display it.

TalkBack

Calm and reassure your baby with the sound of your own voice using the app, from wherever you are.

Specifications

Video Quality

Exposure: Automatic

Resolution: up to 720p HD (1280 x 720)

Video codec: H.264

White Balance: Automatic

Cameras

Ambient light sensor

Aperture: F2.8

Focus mode: Fixed

Sensor: 1.3 Megapixel camera sensor

View angle: Landscape 57.7°, Portrait 44.9°

Focus Length: 0.2 - 3 meters

Camera WiFi: 802.11 b/ g/ n (2.4 GHz, not compatible with 5GHz)

Software

Android compatibility: version 4.4 & above (phone/tablet)

Automatic App update: Automatic camera firmware update

Installation: via Apple App store or Google Play store

iPad compatibility: Version iOS9 & above, iPad 2 and newer

iPhone compatibility: Version iOS9 & above, iPhone 4S and newer

iPod compatibility: Version iOS9 & above, iPodTouch 5th gen and newer

Power

Voltage: 100-240 V

Rated Frequency: 50-60 Hz

Features

Adjustable viewing angle

Digital zoom and pan: Yes, in app feature

Talkback function

Automatic night mode: Infrared

Easy QR code set up

Monitor multiple cameras: 10

Multiple viewers: 3 simultaneously

Night light: Multi color

Soothing lullabies: 10

Day & night vision

What is included

Adapter

Smart baby monitor

Wall mount

