

Philips Avent  
24 Hour Steam Steriliser



SCF276/01

## Keeps contents sterile night and day

Add or remove items at any time

The easiest way to sterilise is with the Philips Avent 24 Hour Steriliser. It keeps contents sterile for 24 hours and the digital display tells you when it is time to re-sterilise. Includes 2 Avent Feeding Bottles and handy accessories.

### Easy to use

- Just add water once a day

### Keeps you informed

- Advanced digital display and sound alerts

### Large capacity

- Holds up to six Philips Avent Bottles

### Fast

- Contents are sterile and ready to use in approx. 6 min.

### Automatic 24 hour sterilisation

- Sterile contents, even if you open the lid

**PHILIPS**  
**AVENT**

# Highlights

## Keeps contents sterile



This advanced steriliser makes sure you always have a sterile bottle at hand by keeping contents sterile for 24 hours. It will automatically re-sterilise the contents every 6 hours. With the handy pause button you can also add or remove items at any time and the 24 Hour Steriliser will automatically re-sterilise the contents.

## Advanced digital display



The display and sound alerts tell you when sterilisation is complete and how long items will remain sterile. The display also lets you know when you have filled the steriliser with too little or too much water, so you can always be sure that sterilising has been completed accurately and reliably.

## Just add water once a day



Aside from its advanced functionality, the 24 Hour Steriliser is simple and straightforward to use. Just add water, load the steriliser with your bottles, breast pump, or accessories, and select the mode. Mode 1 lets you run a single sterilising cycle, which is useful when you want to take all the items out in one go. Mode 2 is for 24 hour sterilising, which is very convenient when you want to leave the items in the steriliser overnight or when you want to take out only one bottle for every feed. No matter what your routine will be, this steriliser will make the daily sterilising chore easier.

## Holds up to six bottles



The steriliser has a smart design that takes up little space in your kitchen, yet still fits six Philips Avent Bottles or two Philips Avent Breast Pumps. The two baskets inside can clip together

to form a dishwasher basket, which makes pre-cleaning of smaller items like soothers and teats much easier.

## Sterile contents in 6 minutes



The advantage of steam sterilisation is that it is much quicker (and safer) than the traditional method of boiling bottles in a pan on the stove. The 24 Hour Steriliser takes as little as 6 minutes to sterilise a full load of 6 bottles, teats, and dome caps.

## Natural steam sterilisation



Sterilising is all about protecting your baby from particularly harmful milk bacteria until his immune system is strong enough. The Philips Avent Steriliser uses the hospital method of steam sterilisation, which is quick, easy, and efficient, with no chemicals involved.

# Specifications

## Country of origin

- England

## Development stages

- Stage: 0 - 6 months

## Power

- Voltage: 220-240 V

## What is included

- Extra soft newborn flow nipple: 2 pcs

## Weight and dimensions

- Dimensions: 320 (H), 230 (W), 230 (L) mm
- Weight: 1.47 kg

## What is included

- Tongs: 1 pcs
- Bottle and nipple brush: 1 pcs
- Newborn Pacifier: 1 pcs

## What is included

- Measuring jug: 1 pcs
- Extra Durable Feeding Bottle: 125ml/4oz, 260ml/9oz



Issue date 2021-03-10

Version: 3.0.1

EAN: 08 71010 35197 51

© 2021 Koninklijke Philips N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips N.V.  
or their respective owners.

[www.philips.com](http://www.philips.com)