



Kitchen Machine

- 900 W
- 7 speeds and pulse
- Easy 6-in 1 set up

HR7950/01

Unbeatable results, easier than you think

Cake, bread, pizza, cookies, smoothies, soups and more

Presenting the all new Philips Kitchen Machine - unbeatable performance and versatility, easier than you thought!

Benefits

Unbeatable kneading, mixing, whisking results

- Powerful 900 W motor for consistent, unbeatable results
- Planetary Mixing Action for thoroughly mixed ingredients
- 7 speeds and pulse for maximum control
- 4L metal bowl for upto 1300gms of dough
- Metal kneading hook, whisk and beater, designed to perform

Easier than you thought

- Unique open arm for full bowl access, easier to attach tools
- Easier to clean with rounded edges, covered hinge
- Quick release suction feet to lift and move effortlessly

PHILIPS

Features

Powerful 900 W motor



Powerful 900 W motor for consistent, unbeatable results.

Planetary Mixing Action



Planetary Mixing Action allows the kneading, mixing and whisking tools to move in a unique backwards and forwards movement rather than just in a simple circle, reaching all corners of the bowl, and resulting in the smooth, thoroughly mixed ingredients.

7 speed control and pulse



Multiple speeds and pulse gives maximum control for unlimited variety of recipes.

4L metal bowl with handle



Large, robust 4L metal bowl can comfortably knead upto 1300gms of dough so you can to make upto 4 12" pizzas or 2 loafs of bread in one go. The metal

handle makes it easy to carry and pour. While the splash guard cover prevents splashing when in use.

Strong metal bowl tools



Metal kneading hook, beater and whisk are easy to lock into place with a simple twist. Specially designed kneading hook mimics kneading by hand to ensure smooth, lump free dough.

Unique open arm for easier use



The open arm swings up in a practical position so you can easily attach and detach the bowl tools. It can be closed again with a simple one hand push. The open arm also offers you full bowl access, a practical feature when checking consistency or adding ingredients.

Easier to clean



Designed with rounded edges and covered gaps for easy, smooth cleaning. Plus dishwasher safe bowl and accessories.

Quick release suction feet

Specially designed quick release suction feet so you can simply pull and lift effortlessly.

Specifications

[field not found 'disclaimer_text']

Accessories included

4L metal bowl	Yes
Metal kneading hook	Yes

Design specifications

Color(s)	White and grey
Housing material	ABS
Material bowl	Stainless steel
Material bowl tools	Stainless steel

Technical specifications

Power	900 W
-------	-------

General specifications

Speeds	7 + pulse
--------	-----------

Packaging dimensions

Height	35.00 cm
Width	40.50 cm
Depth	31.60 cm
Nett weight	4.90 kg
Gross weight	6.39 kg
EAN	08710103725503
Number of products included	1
Country of origin	CN
Harmonised Systems Code	850940

Outer Carton

Length	36.40 cm
Width	33.00 cm
Height	42.00 cm
Gross weight	6.95 kg

Avance Collection

EAN 18710103725500
Number of consumer 1
packagings



data subject to change
2016, November 17
Version: 2.0.1
EAN: 08710103725503

© 2016 Koninklijke Philips N.V.
All rights reserved.

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips N.V. or their respective owners.

www.philips.com