

PHILIPS

Meat mincer

Avance Collection

800 W nominal, 2600 W blocked

4.5kg/min

Stainless steel front

3 grindings, 5 accessory

HR2733/00



High performance mincing, cleaning in seconds

Superior motor design for up to 4.5 kg/min mincing

This high performance Philips Meat Mincer is designed with a powerful motor and a real metal stainless steel front for superior design and durability. After mincing, cleaning is effortless with the innovative cleaning tool.

High performance mincing

- Effortless mincing capacity up to 4.5 kg/min
- Hygienic stainless steel cutting knife stays sharp
- Full metal coupling for heavy duty performance
- Circuit breaker with reset for motor protection
- Optional extra coupling

Easiest set up, assembly and use

- XL grinding screen (65 mm)
- Extra long power cord 1.8 meters
- Includes slicing and shredding drums

Effortless cleaning in seconds

- Innovative 3 sided cleaning tool
- 3 hygienic stainless steel grinding discs (3, 5, 8 mm)



Highlights

Up to 4.5kg/min



Effortless mincing capacity up to 4.5 kg/min

Hygienic stainless steel knife



Hygienic stainless steel cutting knife stays sharp

Full metal gear coupling



The full metal gear coupling is designed to withstand heavy duty mincing.

Motor protection

The circuit breaker gives extra protection to the appliance from damages caused by overload or short circuits. It can be reset as needed to resume normal operations.

Extra coupling



An additional plastic coupling is included for your optional choice and can be useful when mincing fatty or sticky meats.

XL grinding screen (65 mm)



XL grinding screen (65 mm)

Extra long power cord



Extra long power cord (1.8m) enables use in more places



3 hygienic stainless steel grinding discs (3, 5, 8 mm)

Innovative cleaning tool



Innovative 3 sided cleaning tool shortens cleaning time with 50% (patent pending). After mincing, simply click the mincing screen onto the cleaning tool and rinse under running water. No more tedious cleaning of clogged screen holes!



asimpleswitch.com

Philips Green Logo

Philips Green Products can reduce costs, energy consumption and CO2 emissions. How? They offer a significant environmental improvement in one or more of the Philips Green Focal Areas – Energy efficiency, Packaging, Hazardous substances, Weight, Recycling and disposal and Lifetime reliability.

Specifications

Technical specifications

Power cord length: 1.8 m
Blocked power: 2600 W
Nominal power: 800 W

Accessories included

Accessory storage tray
Knife
Meat tray dust cover
Meat tray: Metal

Kebbe maker

Sausage horn diameter: 12 mm, 22 mm
Stainless steel disk diameter: 3 mm, 5 mm, 8 mm

