

PHILIPS

Bagless vacuum cleaner

PowerPro Compact

1800W

PowerCyclone 4

EPA 10 motor filter

FC8472/61



20% higher suction power* for a better clean

With PowerCyclone 4 Technology

The new Philips PowerPro Compact delivers powerful performance without compromises thanks to the PowerCyclone 4 technology and advanced bucket design

Clean air in your home

- The EPA filter catches microscopic vermin causing allergy

Ergonomic grip for far reach

- Reach all corners thanks to the extra long ergonomic grip

Powerful cleaning performance

- 1800 Watt motor for high performance
- PowerCyclone 4 technology separates dust and air in one go

Easy to clean

- Advanced dust container design for easy to emptying

Highlights

1800 Watt Motor



The 1800 Watt motor generates max 350 Watt suction power for high performance.

Easy to empty dust container



The dust container is perfectly designed to dispose dust without creating a dust cloud. Thanks to its unique shape and smooth surface, dust is collected at one side of the container and evenly glides into the dust bin.

PowerCyclone 4 Technology



PowerCyclone 4 technology maximizes airflow and performance by separating dirt from air in one go. It delivers remarkable cleaning results

through highly efficient steps: 1) Air enters fast into the PowerCyclone thanks to the straight and smooth air inlet. 2) The curved airpass quickly accelerates the air upwards in the cyclonic chamber to separate the dust from the air.

EPA filter system



The pleated EPA filter has a large filter surface and good filtration performance. In combination with the cyclonic airflow, this prevents it from clogging fast and gives you better and longer-lasting filtration results.

Extra long ergonomic grip



This ergonomically shaped grip is convenient in use. Its extra long design gives you farther reach, so you can easily clean hard to reach places.

Specifications

Design

Color: Purple Magic

Performance

Input power (max): 1800 W
 Input power (IEC): 1600 W
 Suction power (max): 350 W
 Vacuum (max): 25 kPa
 Airflow (max): 35 l/s
 Noise level (Lc IEC): 84 dB

Filtration

Dust capacity: 1.5 L
 Exhaust filter: Sponge
 Motor filter: Washable foam inlet filter

Usability

Action radius: 9 m
 Cord length: 6 m
 Tube type: Metal 2-piece telescopic tube
 Carrying handle: Front
 Tube coupling: Conical
 Wheel type: Plastic

Nozzles and accessories

Standard nozzle: Multi nozzle
 Accessories included: Crevice tool, Small nozzle

Sustainability

Packaging: > 90% recycled materials
 User manual: 100% recycled paper

Weight and dimensions

Weight of product: 4.5 kg
 Dimensions of product (LxWxH):
 406x285x238 mm

