



Gaggia  
Super-automatic  
espresso machine

- Gaggia Platinum
- Vogue

RI9304/21



GUARANTEES THAT YOUR COFFEE FLOWS INTO THE  
CUP(S)

PLATINUM GRIND THE COFFEE AND BREW IT IN THE CUP

The Gaggia Platinum is a super-automatic espresso machine of exclusive design that will be the highlight of your kitchen. Your best choice for perfect tasting espresso and other coffee variations at the touch of a button.

**Tradizione...**

- 15 bars pressure for full Espresso taste
- Classic milk frother for a tasty Cappuccino

**...in continua evoluzione**

- Easy cleaning thanks to removable brewing group
- Always a clean machine thanks to automatic circuit cleaning
- Adjust your Espresso to fit your taste
- Descaling alarm for longer product lifetime

**GAGGIA**  
MILANO

## HIGHLIGHTS

### Adjust your Espresso



The settings in this Gaggia Espresso machine allow you to adjust the body and aroma of your coffee to suit your taste, while maintaining a perfect crema.

### Automatic cleaning



Thanks to the automatic cleaning and automatic descaling, you are guaranteed a perfect and hygienic Espresso every day and prolong the lifetime of your Gaggia Espresso machine.

### Classic milk frother



The classic milk frother on this Gaggia Espresso machine, traditionally called "Panarello", turns milk into gorgeous milk froth within seconds for a Cappuccino, a Latte Macchiato or more. It also delivers hot water for tea.

### Descaling alarm



Your Gaggia machine will indicate when a descale cycle becomes necessary. Descaling will prolong the lifetime of your Espresso machine significantly and should only be completed with original Gaggia descaler.

### Removable brewing group



The removable brewing group in your full-automatic Espresso machine allows for easy cleaning and maintenance and can even be replaced separately if necessary. This saves money and increases the machine hygiene for a flawless coffee taste.

### 15 Bar



The 15bar pressure of your Gaggia coffee machine will make sure you always get the authentic Espresso taste.

## SPECIFICATIONS

### Weight and dimensions

- Coffee bean capacity: 250 gr
- Waste container capacity: 14 servings
- Water tank capacity: 1,7 L

### Multi-Beverage

- Milk Variations: Pannarello: milk frothing, Milk Island compatible

### Technical data

- Boiler: Stainless steel
- Frequency: 50 Hz
- Power: 1400 W
- Pump Pressure: 15 bar
- Voltage: 230 V

### Features

- Interface: Direct buttons
- Removable watertank

### Perfect Espresso

- Espresso technology: Aroma-system: pre-brewing, Saeco adapting system, SBS: creme adaptor

### Energy saving

- Energy saving: Automatic stand-by