



**Saeco Exprelia Evo
Super-automatic
espresso machine**

- Brews 7 coffee varieties
- Integrated milk jug & frother
- Stainless steel
- 5 step adjustable grinder



HD8857/01

Perfect, hot, clean.

That's the premium milk froth experience

Only the Saeco Exprelia EVO espresso machine delivers the ultimate milk experience thanks to the new H2 Technology Milk Carafe and the full bean to cup customization

Authentic Italian coffee perfection

- Perfect froth thanks to the dual chamber milk carafe
- Milk specialties without the wait thanks to a double boiler
- Coffee without burnt taste thanks to 100% ceramic grinders

Set the beverages to suit your taste

- Save your favorite coffee settings
- Play with the coffee's richness with our adjustable grinders
- Boost coffee crema and body

Ease of cleaning and maintaining

- Always a clean machine thanks to auto-clean and descaling
- Hygienic milk frothing thanks to automated dual cleaning
- Easy cleaning thanks to removable brewing group
- Cutting-edge design with stainless steel finish

High comfort is part of the experience

- Proven hygiene with the patented steam cleaning carafe

 **Saeco**

PHILIPS

Saeco, a Philips brand



Highlights

Stainless steel



The cutting-edge design of your Saeco espresso machine is rounded off by the stainless steel finish. The stainless steel provides a high quality look and will be a highlight on your kitchen counter tops. It also gives greater resistance for a long-lasting performance.

100% ceramic grinders



This espresso machine is equipped 100% ceramic grinders. Saeco uses ceramic grinders because of their consistent grind without overheating the coffee bean for an impeccable espresso. Ceramic also ensures long-lasting performance and a totally silent operation.

Dual chamber milk carafe



Enjoy your milk specialties fully automated with the patented milk carafe with dual chamber technology. Simply pour milk into the carafe, plug it into the machine and select your coffee drink. With the dual chamber technology you will always enjoy professional coffee drinks with dense, long-lasting milk froth at the ideal temperature from a constant splash-free flow of milk.

8 step adjustable grinders



Different coffee blends require different levels of granularity for the full flavor to unfold. The grind granularity of this espresso machine can be adjusted in 8 settings, from the finest grind,

for a full bodied espresso, to the coarsest, for a lighter coffee.

Saves your coffee settings



You will always get a perfect cup of espresso brewed just for you, according to your personal preference, thanks to our innovative memo function to adjust the coffee length, strength and temperature. Enjoy a superb coffee drink in your favorite cup with just the press of a button.



asimpleswitch.com

Philips Green Logo

Philips Green Products can reduce costs, energy consumption and CO2 emissions. How? They offer a significant environmental improvement in one or more of the Philips Green Focal Areas – Energy efficiency, Packaging, Hazardous substances, Weight, Recycling and disposal and Lifetime reliability.

Specifications

Sustainability

- Automatic Stand-by Option

Perfect Espresso

- Espresso technology: Saeco adapting system, Aroma-system: pre-brewing, SBS: creme adaptor

Service

- 2-year worldwide guarantee

Multi-Beverage

- Milk Variations: Integrated auto milk function, Milk quantity selector, Removable milk carafe

Easy to use

- Cleaning and maintenance: Automatic coffee circuit rinse, Automatic milk circuit rinse, Descaling cycle
- Usage: Adjustable coffee dispenser, Bypass for grinded coffee, Frontal access to all function, Instant steam (2 boilers), Removable brewing group, Removable watertank

Energy saving

- Energy saving: Automatic stand-by

Weight and dimensions

- Product dimensions (L x D x H): 245 x 420 x 360 mm
- Coffee bean capacity: 300 gr
- Waste container capacity: 11 servings
- Milk carafe capacity: 0.5 L
- Water tank capacity: 1.5 L
- Maximum cup height: 150 mm
- Product weight: 16.1 kg

Design

- Colour: Stainless steel
- Materials and finishing: Stainless steel

Technical specifications

- Number of water boilers: 1 boiler
- Water pressure in pump: 15 bar (perfect espresso)
- Supported coffee types: Ground coffee, Whole coffee beans
- Country of origin: Made in Italy, Designed in Italy
- Removable brewing group
- Cord length: 80 cm
- Boiler material: Stainless steel (Inox)
- Frequency: 50 Hz
- Power: 1400 W
- Voltage: 230 V

