PHILIPS

Vacuum cleaner with bag

Performer Active

2100 W

HEPA 13 filter

4L

Turbo brush



FC8588/01





High suction power for a deep clean Hygienic cleaning with AirflowMax

The new Philips Performer Active vacuum cleaner delivers full cleaning performance with hygienic dust removal. AirflowMax technology keeps the suction power stronger for longer*. The MultiClean nozzle removes dust efficiently on all floors.

Remarkable cleaning results

- Revolutionary AirflowMax technology for strong suction power
- Powerful 2100 Watt motor for excellent cleaning results
- $\cdot\,$ New MultiClean nozzle for thorough cleaning on all floors
- Turbo brush, perfect for homes with pet hair

Maximum convenience

- Integrated brush for ultimate convenience
- ActiveLock couplings to easily adjust to each cleaning task
- Soft bumper for easy gliding along furniture and walls
- 4L dust capacity for longer cleaning

Hygienic cleaning

- Allergy filter captures more than 99.90% of fine dust
- s-bag Classic Long Performance lasts up to 50% longer

FC8588/01

Highlights

AirflowMax technology



The unique AirflowMax technology keeps the suction power stronger for longer* to use the bag to the very end. The technology is build around the optimization of three key elements: 1) Unique ribs profile inside the dust chamber to maximize airflow around the dustbag and enable the use of the entire bag surface. 2) Specially designed dust chamber capacity that allows the dustbag to fully unfold uniformly. 3) High quality, non-clogging fibre structures in the dustbag absorb dust without blocking the pores, thus avoiding a reduction in suction power.

Integrated Brush



The vacuum cleaner is designed with integrated accessories, so that you do not need to carry extra pieces around while you clean. The soft dusting brush is coveninently integrated in the handle of the appliance, always ready to use.

ActiveLock couplings



The ActiveLock couplings allow you to easily connect and disconnect the different nozzles and accessories from the telescopic tube while cleaning.

Soft bumper



The soft bumper protects furniture and prevents damage if you accidentally bump into your furniture or walls and stops it from getting stuck on edges, so you can move around faster.

Allergy filter



Developed to meet the specific needs of allergy sufferers and more generally of people demanding a higher level of hygiene.

s-bag Classic Long Performance



This new Philips synthetic dust bag has been developed to provide long lasting vacuum cleaner performance, i.e. a high performance level and maximum filtration, up to the moment the dust bag is full and ready for disposal.



The specially designed 4L dust chamber allows you to make optimal use of your dust bag, so you can clean for longer.



The Turbo brush allows deep cleaning of carpets, easily removing hair and fluff. The rotating brush inside the nozzle actively removes small dust particles and pet hair, resulting in a better cleaning performance.

MultiClean nozzle



The new MultiClean nozzle delivers a thorough cleanining on all types of floors. The nozzle is designed with a large front opening to pick up big crumbs, while at the same time it seals closely to the floor to ensure a good pick-up of the fine dust.

Specifications

Performance

Airflow (max): 40,17 l/s Input power (IEC): 1800 W Input power (max): 2100 W Sound power level: 82 dB Suction power (max): 450 W Vacuum (max): 23 kPa

Usability

Action radius: 9 m Carrying handle: Front Cord length: 6 m Tube type: Metal 2-piece telescopic tube Wheel type: Rubber Tube coupling: ActiveLock Power control: Rotary knob

Design Color: Dark Royal Blue

Filtration

Dust bag type: s-bag Classic Long Performance Dust capacity: 4 L Exhaust filter: Allergy filter Motor filter: Microfilter FC8588/01

Nozzles and accessories

Accessories included: Crevice tool, Integrated brush Additional nozzle: Turbo brush Standard nozzle: MultiClean nozzle

Sustainability

Packaging: > 90% recycled materials User manual: 100% recycled paper

Weight and dimensions

Dimensions of product (LxWxH): 447x304x234 mm Weight of product: 5,2 kg

© 2019 Koninklijke Philips N.V. All Rights reserved. Issue date 2019-02-12 Version: 12.6.1



* Suction power of Philips Perfromer Active compared to suction power of Philips Powerlife FC8322/09, as tested according IEC 60312-1:2011

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips N.V. or their respective owners.

www.philips.com