



Gaggia  
Super-automatic  
espresso machine

- Gaggia Platinum
- Vogue

RI8174/00

HAVE A PERFECT ESPRESSO JUST PRESSING A BUTTON

PLATINUM GRIND THE COFFEE AND BREW IT IN THE CUP

automatically

**Features**

- Adjust your Espresso to fit your taste

**Ease of cleaning and maintaining**

- Descaling alarm for longer product lifetime
- Always a clean machine thanks to auto-clean and descaling
- Easy cleaning thanks to removable brewing group

**Easy to use**

- Clear led display
- Delicious milk froth thanks to the classic milk frother

**GAGGIA**  
MILANO

## HIGHLIGHTS

### Clear led display



Clear led display

### Descaling alarm



Your Gaggia machine will indicate when a descale cycle becomes necessary. Descaling will prolong the lifetime of your Espresso machine significantly and should only be completed with original Gaggia descaler.

### Auto cleaning and descaling



Saeco designed this espresso machine to automatically clean its coffee circuit with water upon starting up or switching off of the machine, this delivers a great, fresh taste with each cup of coffee. Regular descaling prolongs your espresso machine's life. This machine will not only prompt when descaling is needed, the automated descaling process will start on your machine and guides you with clear on-screen messages when you have to intervene. Descaling has never been so easy!

### Classic milk frother



This Saeco espresso machine comes with the classic milk frother that baristas call a "Pannarello". It dispenses steam and is immersed in milk to prepare gorgeous milk foam. Unleash your inner barista by preparing your delicious milk specialties the traditional way!

### Removable brewing group



The brewing group, a Saeco invention, is the heart of our espresso machines, ensuring automation. The brewing group is, depending on the model, easily accessible from the front or side. It can be removed effortlessly for easily cleaning by rinsing under the tap ensuring maximum hygiene.

### Adjust your Espresso



The settings in this Gaggia Espresso machine allow you to adjust the body and aroma of your coffee to suit your taste, while maintaining a perfect crema.

## SPECIFICATIONS

### Weight and dimensions

- Coffee bean capacity: 250 gr
- Waste container capacity: 14 servings
- Water tank capacity: 1,7 L

### Multi-Beverage

- Milk Variations: Pannarello: milk frothing, Milk Island compatible

### Technical data

- Boiler: Stainless steel
- Frequency: 50 Hz
- Power: 1400 W
- Pump Pressure: 15 bar
- Voltage: 230 V

### Features

- Interface: Direct buttons
- Removable watertank

### Perfect Espresso

- Espresso technology: Aroma-system: pre-brewing, Saeco adapting system, SBS: creme adaptor