PHILIPS

Steam generator iron

PerfectCare Aqua Silence

Up to 6.2 bar pressure 330 g steam boost Carry lock 2.5 L fixed watertank

GC8650



Ultra fast and quiet ironing

with no temperature adjustment required

Iron any ironable garment from silk, to linen, to cotton, to cashmere...in any order, without having to adjust. Your Philips PerfectCare Iron delivers fast results without risk of burn or shine for all your garments. Truly simple ironing.

Carefree ironing, no temperature setting required

- Silent steam technology: Powerful steam with minimum sound
- Safe to leave the hot soleplate on the ironing board
- Iron from jeans to silk with no temperature setting required

Fast and powerful ironing

- Saving energy with ECO mode
- Tap water friendly, refill anytime during ironing
- Automatically turned off for peace of mind and energy saving
- Our best gliding soleplate
- Ready to use in 2 minutes with unlimited refill
- Descale effectively and easily your appliance to prolong it
- Up to 6.2 bar pressure
- Lock your iron securely to the base station
- Large 2.5 L fully visible water tank

Highlights

Steam ready in 2 minutes

Steam is ready to use in 2min and can be refilled at anytime during ironing.

Refill tap water any time

Your steam generator iron is designed to use tap water. While ironing, when you run out of water in the watertank, you can refill it easily without waiting or turning your appliance off.

Easy De-Calc

Ultra long lasting steam performance: Philips' exclusive Easy De-Calc function provides the ideal way to get rid of limescale and extend the lifetime of your steam generator iron. Your iron will remind you with light and sound when to perform cleaning. Only when your appliance is cold, simply open the Easy De-Calc knob, and collect the dirty water and scale in a cup.

Up to 6.2 bar pressure

The more steam, the faster the ironing. Consistent powerful steam is generated which penetrates deep inside the garments making ironing faster and better. Steam power can be regulated to fit your needs.

Safe rest

The Philips innovative OptimalTEMP technology guarantees no burn on all ironable fabrics. During ironing, no need to put your iron back to the base station, just leave the hot iron soleplate directly on the garments or cotton ironing board cover without additional resting accessory. It will not damage any of your ironable garments, neither the board. This makes your ironing easier with less wrist efforts.

Energy saving

By using the ECO mode , with reduced amount of steam, you can save energy without compromising on the ironing results.

Silent steam Technology

Enjoy ironing with family around or while watching TV, without being disturbed by the noise of the steam. Silent steam technology delivers quiet yet very powerful steam. The steam generator is fitted with silencing steam filters to reduce the noise of the steam, and a sound-absorbing platform to reduce the noise of the pump in the base.

Automatic shut-off

The auto off function automatically switches off the appliance if it has not been used for a few minutes, also saving energy.

T-ionicGlide soleplate

Our best gliding and most scratch resistant, 5star rated soleplate with integrated Titanium-Oxide layer

Safety carry lock

Your steam generator iron comes with a safety carry lock. You can lock your iron safely on the base, making it safer, reducing the risk of people touching the hot soleplate. You can also carry the steam generator easily.

OptimalTEMP technology

Now you can iron from jeans to silk with no temperature setting required. Guaranteed no burn on all ironable fabrics. Revolutionary technology with the 1) Advanced Smart Control Processor which controls precisely the soleplate temperature. You do not need to adjust temperature 2) Powerful Cyclonic steam chamber which delivers powerful consistent steam, making ironing easier and faster.

2.5 L fully visible water tank

The extra large 2,5 L watertank ensures up to 3 hours ironing without any refilling. It makes your ironing faster and easier. Thanks to the clear watertank, you can see the water level from any angle and ensure you still have enough water to steam efficiently.

Specifications

Fast & powerful crease removal

Soleplate: T-ionicGlide OptimalTEMP technology Safe rest Silent Steam Technology Vertical steaming Steam tip Power: 2400 W Steam boost: 330 g Pressure: Up to 6.2 bar pressure

Easy to use

Safe for all fabrics: Even for delicates like silks Water tank capacity: 2500 ml Filling and emptying water: Extra large filling hole Refill any time Heat up time: 2 min Safety auto off Storage solution: Carry lock Cord freedom (swivel): 180 degree cord freedom Low water alarm Cord storage: Cord clip Power cord length: 1.8 m Hose storage: Hose storage compartment Hose length: 1.7 m

Sustainability

Energy saving mode

Calc management

Suitable for tap water Calc clean reminder Calc clean solution: Easy De-calc

Technical specifications

Weight of iron: 1.1 kg Weight of iron + base: 4.5 kg Product dimensions: 36.2 x 27 x 26.3 cm Voltage: 220 - 240 V

© 2019 Koninklijke Philips N.V. All Rights reserved.

Specifications are subject to change without notice. Trademarks are the

Issue date 2019-09-19 Version: 1.0.1





property of Koninklijke Philips N.V. or their respective owners.