

PHILIPS

Pressurised steam
generator

GC7230



Faster ironing – from start to finish

Pressurised steam power with fast-fill water tank

Created to speed up ironing from start to finish, GC7230 is ready to use in 2 minutes. Pressurised steam power speeds up ironing by penetrating deeper into fabric and the extra-large water-filling funnel allows fast & easy refills anytime.

Full control

- Variable steam settings to suit every garment

Smooth gliding

- SteamGlide soleplate for powerful steam and superb gliding

Reaches into tricky areas

- Steam tip lets you iron right into hard-to-reach areas

Fast and powerful ironing

- Up to 4 bars of steam pressure for fast ironing
- Ready to use in 2 minutes
- Continuous steam up to 80 g/min for fast crease removal
- Water-filling funnel allows fast and easy refills anytime

Comfortable ironing

- Steam trigger lock gives steam without needing to press down

Highlights

Steam tip

The unique steam tip combines a particularly pointed front of the soleplate with special steam slots in the tip to reach right into the smallest and most difficult areas for the best ironing results.

Up to 4 bars steam pressure



Double your ironing speed with pressurized steam. Pressurized steam penetrates deep into fabrics, making your ironing fast and easy, even on difficult fabrics.

Quick start-up

When switched ON, the ironing system is ready for steam ironing in just 2 minutes.

Continuous steam up to 80 g/m

Continuous steam up to 80 g/min helps to efficiently remove all creases.

Extra-large water-filling funnel

Filling your iron's water tank has never been faster or easier. Simply open the easy-access lid and pour in the water. The large, funnel-like opening ensures quick, convenient filling without the risk of spillage. And water can be added anytime – before, during or after an ironing session – without having to wait for the iron to cool down.

Steam trigger lock

The steam trigger lock allows a user the possibility to have continuous steaming of the iron without having to press the trigger continuously.

SteamGlide Soleplate



This specially designed soleplate combines superior ceramic coating for superior gliding on all fabrics and carefully designed vents for powerful crease removal.

Specifications

Longer lifetime

Inox boiler with external heating element: Anti-corrosion steam chamber
Calc-Clean: Simply rinse the boiler every 10 ironing sessions

Easily removes creases

Optimal vent pattern: For the best steam distribution
Continuous vertical steam: For hanging fabrics

Reaches into tricky areas

Button groove: Speeds up ironing along buttons and seams

Comfortable ironing

Steam trigger lock: Gives steam without needing to press down
Extra long hose for maximum reach: 1.7 m
Extra-long cord for maximum reach: 2.0 m
Suitable for tap water

Easy set up and storage

Cord and hose storage cap: Allows for quick & easy storage of cord and hose

Safe ironing

Overheat safety stop: Prevents the boiler from overheating
Four rubber feet: Ensure the stand does not slip
Stable heel rest: Keeps the iron stable when standing

Full control

Iron temperature ready light
Steam-ready light: Indicator shows when right steam level is reached
Water tank empty light: Indicator shows when water tank needs refilling

Technical specifications

Frequency: 50-60 Hz
Voltage: 230 V
Iron wattage: 800 W
Boiler wattage: 1400 W

Weight and dimensions

Dimensions: 429x400x206 mm
Weight (incl. packaging): 6.1 kg
Pallet: 254 (Europallet) ; 399 (ROW) pcs

