

PHILIPS

Saeco

Super-automatic
espresso machine

Exprelia

Integrated milk jug and frother

Stainless steel

5-step adjustable grinder

HD8856/08



Perfect, hot, clean.

That's the premium milk froth experience

The Exprelia is always ready to serve your favourite coffee speciality. Thanks to the immediate beverage selection interface, whatever you choose is made at the touch of a button — and instantly prepared thanks to the machine's double boiler.

Authentic Italian coffee perfection

- Perfect milk froth thanks to the integrated milk carafe
- Milk specialities without the wait thanks to a double boiler
- Coffee without burnt taste thanks to 100% ceramic grinders

Set the beverages to suit your taste

- Save your favourite coffee settings
- Play with the coffee's richness with our adjustable grinders
- Boost coffee crema and body

Easy to clean and maintain

- Always a clean machine thanks to auto-clean and descaling
- Hygienic milk frothing thanks to automated dual cleaning
- Easy cleaning thanks to removable brewing group
- Cutting-edge design with stainless steel finish

Highlights

Stainless steel



The cutting-edge design of your Saeco espresso machine is rounded off by the stainless steel finish. The stainless steel provides a high-quality look and will be a highlight on your kitchen counter tops. It also gives greater resistance for a long-lasting performance.

100% ceramic grinders



This espresso machine is equipped with 100% ceramic grinders. Saeco uses ceramic grinders because of their consistent grind without overheating the coffee bean, for an impeccable espresso. Ceramic also ensures long-lasting performance and totally silent operation.

8-step adjustable grinders



Different coffee blends require different levels of granularity for the full flavour to unfold. The grind granularity of this espresso machine can be adjusted in 8 settings, from the finest grind, for a full-bodied espresso, to the coarsest, for a lighter coffee.

Saves your coffee settings



You will always get a perfect cup of espresso brewed just for you, according to your personal preference, thanks to our innovative memo function for adjusting the coffee length, strength and temperature. Enjoy a superb coffee drink in your favourite cup at the touch of a button.

Removable brewing group



The brewing group, a Saeco invention, is the heart of our espresso machines, ensuring automation. The brewing group is, depending on the model, easily accessible from the front or side. It can be removed effortlessly for easy cleaning by rinsing under the tap, ensuring maximum hygiene.

Automatic dual-cleaning carafe



This Saeco espresso machine comes with a fully automated dual-clean function for its milk carafe. The dual cleaning uses two independent steam cycles to swiftly rinse your

milk carafe after each coffee drink you prepare, for a fresh milk drink every time. Hygienic milk frothing has never been this easy.

Auto-cleaning and descaling



Saeco designed this espresso machine to automatically clean its coffee circuit with water when starting up or switching off to deliver a great, fresh taste with each cup of coffee. Regular descaling prolongs your espresso machine's life. This machine will not only prompt when descaling is needed, the automated descaling process will start and guide you with clear on-screen messages when you have to intervene. Descaling has never been so easy!

Professional double boiler



With 2 separate heating systems to cater for both the optimal coffee temperature and the milk frothing temperature, this Saeco fully automatic espresso machine guarantees professional performance and speed every time. You are able to prepare as many latte macchiatos and cappuccinos as you wish, one after the other and each just as good as the previous one, without waiting.

Specifications

Technical specifications

Boiler material: Stainless steel (Inox)

Number of water boilers: 1 boiler

Water pressure in pump: 15 bar (perfect espresso)

Supported coffee types: Ground coffee, Whole coffee beans

Country of origin: Made in Italy, Designed in Italy

Removable brewing group

Power: 1500 W

Voltage: 240 V

Frequency: 50 Hz

Cord length: 80 cm

Sustainability

Automatic Standby Option

Perfect Espresso

Espresso technology: Saeco adapting system, Aroma-system: pre-brewing, SBS: creme adaptor

Service

2-year worldwide guarantee

Multi-Beverage

Milk Variations: Integrated auto milk function, Milk quantity selector, Removable milk carafe

Easy to use

Cleaning and maintenance: Automatic coffee circuit rinse, Automatic milk circuit rinse, Descaling cycle

Usage: Adjustable coffee dispenser, Bypass for

grinded coffee, Frontal access to all functions, Instant steam (2 boilers), Removable brewing group, Removable water tank

Weight and dimensions

Maximum cup height: 150 mm

Product weight: 14.2 kg

Product dimensions (L x D x H): 245 x 360 x 420 mm

Coffee bean capacity: 300 gr

Waste container capacity: 11 servings

Milk carafe capacity: 0.5 l

Water tank capacity: 1.5 l

