

Philips SpeedCare
Steam generator iron

Max 4.8 bar pump pressure

160 g steam boost

Carry lock

1.2 L fixed watertank

GC6627



Faster and easier ironing**

with 2 times more steam** than a steam iron

Philips SpeedCare steam generator delivers more steam than a steam iron, it helps you speed up ironing. Enjoy more quality time of the reduced ironing time with your loved family by using Philips SpeedCare steam generator iron.

Fast and powerful ironing

- Ready to use in 2 minutes with unlimited refill
- Lock your iron securely to the base station
- Continuous steam up to 110 g/min
- Automatically turned off for safety and energy saving
- Triple precision tip for optimal control and visibility
- Compact size and light weight for easy storage
- Smart Calc clean system with sound&light Calc Clean reminder
- 1.2 L water tank and refill anytime during ironing
- Max 4.8 bar pump pressure

PHILIPS

Steam generator iron
Max 4.8 bar pump pressure 160 g steam boost, Carry lock, 1.2 L fixed watertank

GC6627/30R1

Highlights

Steam ready in 2 minutes



Steam is ready to use in 2min and can be refilled at anytime during ironing.

Safety carry lock



Your steam generator iron comes with a safety carry lock. You can lock your iron safely on the base, making it safer, reducing the risk of people touching the hot soleplate. You can also carry the steam generator easily.

Continuous steam



The more steam, the faster the ironing. The unique technology in a Philips steam generator iron generates powerful steam making ironing easier, better and faster.

Automatic shut-off



The safety auto off function automatically switches off the appliance if it has not been used for a few minutes, also saving energy.

Triple precision tip



The tip of this Philips iron is precise in 3 ways: it has a pointed tip, button groove and a sleek design of the nose. Triple Precision tip enables you to reach even into the most tricky areas, e.g. around the buttons or between the pleats.

Compact size and light weight



Thanks to the revolutionnary ProVelocity technology, we made your steam generator iron more compact than ever before. The compact steam generator fits easily on your

ironing board making your ironing more convenient. In addition, your steam generator takes much less storage space.

Smart Calc Clean system



Smart Calc Clean system is an intergrated descaling and cleaning fuction to protect your steam generator iron. After each about 10 hour ironing, you will be reminded by the soud and light of your steam genreator iron to perform calc clean process. The Calc Clean Container will provide you the convenience during the Calc Clean process, by just resting your iron on the container without holding your iron to stress your waist. After cleaning process, all the dirty water is collected in the container, your steam generator iron is ready to use again.

1.2 L water tank



SpeedCare steam generator has 1.2 L water tank capacity to allow your iron more than 1 hour, it helps you reduce the frequency of refilling everytime for the big laundry loads. The technology will also allow you refill the water tank during ironing without cooling down the appliance for 2 hours waiting to reill.

Steam generator iron

Max 4.8 bar pump pressure 160 g steam boost, Carry lock, 1.2 L fixed watertank

GC6627/30R1

Specifications

Easy to use

- Water tank capacity: 1200 ml
- Cord freedom (swivel): 180 degree cord freedom
- Hose length: 1.6 m
- Power cord length: 1.8 m
- Safety auto off
- Cord storage: Cord clip
- Filling and emptying water: Extra large filling hole, Large filling hole
- Heat up time: 2 min
- Hose storage: Hose storage compartment
- Refill any time
- Storage solution: Carry lock
- Ultra light and comfortable

Calc management

- Calc clean reminder
- Calc clean solution: Smart Calc Clean
- Filtered water recommended
- Suitable for tap water

Fast & powerful crease removal

- Continuous steam output: 110 g/min

- Power: 2400 W
- Pressure: Max 4.8 bar pump pressure
- Soleplate: SteamGlide Ceramic
- Steam boost: 160 g
- Steam output control
- Vertical steaming

Accessories

- Calc Clean container

Service

- 2-year worldwide guarantee

Weight and dimensions

- Packaging dimensions (WxHxL): 26.4 x 30.3 x 40.4 cm
- Weight of iron: 1.1 kg
- Weight of iron + base: 2.6 kg

Technical specifications

- Voltage: 220 - 240 V



Issue date 2019-09-19

Version: 1.0.1

12 NC: 0000 041 02759
EAN: 87 10895 68843 7

© 2019 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com