

# PHILIPS

Food processor

350 W

2.1 L bowl



HR7605/10



## The versatile space saver

### Easily stored food processor

This Philips Food Processor is a space-saving, time-saving multifunctional answer to all your kitchen problems. With this one appliance you can handle over 15 different jobs in a fraction of the time it would normally take.

#### Powerful precision

- Powerful 350 Watt motor for the toughest ingredients
- Easily performs 15+ functions

#### Compact

- All accessories fit in the bowl for compact storage
- Small enough to fit easily in any cupboard

# Highlights

## Ultracompact



Small enough to fit easily in any cupboard

## MicroStore



Microstore allows you to store all your accessories inside the bowl for easy and compact storage.

## 15+ functions



The Food Processor comes with 5 different accessories that enable it to perform 15+ different functions. The – dishwasher safe – accessories are a kneading tool for mixing batter and for heavy kneading. A stainless steel chopping knife to prepare meat and vegetables. Metal disk inserts to handle medium shredding, medium slicing and granulating. And an emulsifying disk to prepare food like whipped cream and mayonnaise.

## Accessories

**Number of inserts/discs:** 3

**Shredding insert medium:** For medium shredding of vegetables and fruit

**Slicing insert medium:** For medium slicing of vegetables and fruits

**Granulating insert medium:** For granulating of potatoes, cheese

**Emulsifying disc:** Whipping, Whisking, Emulsifying application

**Stainless steel chopping knife:** chopping, blending, kneading, pureeing, mixing

## Design specifications

**Housing:** PP

**Switch and toolholder:** POM

**Bowl, cover, pusher:** SAN

**Emulsifying disc:** ABS

**Metal knife and inserts:** stainless steel & ABS

## Technical specifications

**Motor:** Universal, radio/tv interference suppressed

**Power:** 350 W

**Cake batter capacity:** 250 g

**Bowl content:** 2.1 L

**Voltage:** 220–240 V

**Frequency:** 50–60 Hz

**Color(s):** White with mineral green accents

**Safety:** Automatic resettable cut-off protecting the motor

**Speeds:** 1+ pulse

**Cord length:** 75 cm

## Country of origin

Hungary

