



Gaggia
Super-automatic
espresso machine

• Gaggia Brera

RI9305/11



PRESS A BUTTON AND ENJOY YOUR FAVORITE ESPRESSO

COMPACT, TRADITIONAL DESIGN AND SIMPLE TO USE

Espresso as tasty as from the Barista in your favorite café? No problem! The Gaggia Brera espresso machine gives you professional results, right in the comfort of your kitchen. Select the espresso strength and length just as you like.

Tradizione...

- Durable ceramic grinder for pure coffee aroma
- Stainless steel body for long-lasting performance
- 15 bars pressure for full Espresso taste
- Pre-brewing for flavor enhancing
- Ground coffee compartment for more variety in taste

...in continua evoluzione

- Easy cleaning thanks to removable brewing group
- Always a clean machine thanks to automatic circuit cleaning
- Digital display for easy navigation
- Descaling alarm for longer product lifetime
- Energy-saving Stand-by mode

GAGGIA
MILANO

HIGHLIGHTS

Automatic cleaning



Thanks to the automatic cleaning and automatic descaling, you are guaranteed a perfect and hygienic Espresso every day and prolong the lifetime of your Gaggia Espresso machine.

Durable ceramic grinder



Because a metal grinder might burn the coffee beans while grinding, all Gaggia's Espresso machines are equipped with an extremely durable ceramic grinder. A ceramic grinder will retain the purity of the coffee aroma while being equally durable to a metal grinder. Additionally the coffee grind can be adjusted from coarse to fine, just as you prefer.

Descaling alarm



Your Gaggia machine will indicate when a descale cycle becomes necessary. Descaling will prolong the lifetime of your Espresso machine significantly and should only be completed with original Gaggia descaler.

Digital display



Whatever you want to do with your Gaggia - the digital display makes navigation much easier and gives instant feedback on the status of your Espresso machine.

Ground coffee compartment



The ground coffee compartment allows you to brew a different blend of coffee without

changing the beans. Simply switch your Espresso machine to ground coffee and fill the amount for one Espresso into the compartment.

Pre-brewing



Pre-brewing ensures that the ground coffee is evenly moistened before the actual brewing process. Only then the water flows through all of the ground coffee and your Gaggia Espresso machine can extract the full aroma for a balanced and tasty Espresso.

Removable brewing group



The removable brewing group in your full-automatic Espresso machine allows for easy cleaning and maintenance and can even be replaced separately if necessary. This saves money and increases the machine hygiene for a flawless coffee taste.

SPECIFICATIONS

Technical specifications

- Number of water boilers: 1 boiler
- Supported coffee types: Ground coffee, Whole coffee beans

Service

- 2-year worldwide guarantee

Weight and dimensions

- Product dimensions: 45.5 x 33.0 x 42.5 cm
- Coffee bean capacity: 250 gr
- Waste container capacity: 8 servings
- Product weight: 8,5 kg
- Water tank capacity: 1,2 L
- Maximum cup height: 120 mm

Multi-Beverage

- Milk Variations: Pannarello: milk frothing

Technical data

- Boiler: Stainless steel

- Frequency: 50 Hz
- Power: 1400 W
- Pump Pressure: 15 bar
- Voltage: 230 V

Perfect Espresso

- Espresso technology: Saeco adapting system

Design

- Colour: black/silver
- Materials and finishing: abs/stainless steel

Energy saving

- Energy saving: Automatic stand-by

Features

- Brita Filter compatible
- Cupholder
- Hot water / Steam Nozzle
- Pannarello: Stainless Steel