

PHILIPS

Steam generator
iron

PerfectCare Expert

Up to 6.5 bar pressure

260 g steam boost

Carry lock

1.5 L detachable watertank

GC9240/02



Ultra fast ironing

with no temperature adjustment required

Iron any ironable garment from silk, to linen, to cotton, to cashmere...in any order, without having to adjust. Your Philips PerfectCare iron delivers fast results without risk of burn or shine for all your garments. Truly simple ironing.

Carefree ironing, no temperature setting required

- Iron from jeans to silk with no temperature setting required
- Safe to leave the hot soleplate on the ironing board
- Tested and approved by independent textile experts

Fast and powerful ironing

- Ready to use in 2 minutes with unlimited refill
- 1.5 L detachable water tank, up to 2 hours of ironing
- Descale effectively and easily your appliance to prolong it
- New SteamGlide soleplate is Philips premium soleplate
- Lock your iron securely to the base station
- Steam boost up to 260 g
- Up to 6 bar pressure



asimpleswitch.com



asimpleswitch.com

Highlights

Steam ready in 2 minutes



Steam is ready to use in 2min and can be refilled at anytime during ironing.

1.5 L detachable water tank

The watertank can be removed to be refilled easily under the tap. The large filling hole makes the refilling fast. Thanks to the 1.5 L watertank capacity, you can iron up to 2 hours continuously without any refills.

Easy De-Calc



Ultra long lasting steam performance: Philips' exclusive Easy De-Calc function provides the ideal way to get rid of limescale and extend the lifetime of your steam generator iron. Your iron will remind you with light and sound when to perform cleaning. Only when your appliance is cold, simply open the Easy De-Calc knob, and collect the dirty water and scale in a cup.

New SteamGlide soleplate

New SteamGlide soleplate is the best Philips soleplate. It has great scratch resistancy, glides excellent and is easy to clean.

OptimalTEMP technology



Now you can iron from jeans to silk with no temperature setting required. Guaranteed no burn on all ironable fabrics. Revolutionary technology with the 1) Advanced Smart Control Processor which controls precisely the soleplate temperature. You do not need to adjust temperature 2) Powerful Cyclonic steam chamber which delivers powerful consistent steam, making ironing easier and faster.

Safe rest



The Philips innovative OptimalTEMP technology guarantees no burn on all ironable fabrics. During ironing, no need to put your iron back to the base station, just leave the hot iron soleplate directly on the garments or cotton ironing board cover without additional resting accessory. It will not damage any of your ironable garments, neither the board. This makes your ironing easier with less wrist efforts.

Safety carry lock



Your steam generator iron comes with a safety carry lock. You can lock your iron safely on the base, making it safer, reducing the risk of people touching the hot soleplate. You can also carry the steam generator easily.

Steam boost up to 260 g



The steam boost can be used for vertical steaming and tough creases.



asimpleswitch.com

Philips Green Logo

Philips Green Products can reduce costs, energy consumption and CO2 emissions. How? They offer a significant environmental improvement in one or more of the Philips Green Focal Areas – Energy efficiency, Packaging, Hazardous substances, Weight, Recycling and disposal and Lifetime reliability.

Specifications

Fast & powerful crease removal

Soleplate: SteamGlide
OptimalTEMP technology
Continuous steam output: 120 g/min
Steam boost: 260 g
Vertical steaming
Pressure: Up to 6
Steam tip
Power: 2400 W
Safe rest
Steam output control
Variable steam settings

Easy to use

Water tank capacity: 1500 ml
Filling and emptying water: Detachable water tank, Extra large filling hole
Refill any time
Heat up time: 2 min
Safety auto off
Storage solution: Carry lock
Hose storage: Hose storage compartment
Cord storage: Cord storage compartment
Power cord length: 1.8 m
Cord freedom (swivel): 180 degree cord freedom
Hose length: 1.7 m
Safe for all fabrics: Even for delicates like silks

Calc management

Suitable for tap water
Calc clean solution: Easy De-calc
Calc clean reminder

Sustainability

Energy saving mode

Weight and dimensions

Weight of iron: 1.2 kg
Weight of iron + base: 5 kg

