

PHILIPS

Food processor

Avance Collection

1300 W

Compact 3-in-1 setup

3.4 L bowl



HR7776/91



Maximum variety of recipes, minimum effort

Create homemade breads, cakes, drinks and more

This Philips Avance collection Food Processor is the versatile solution for your kitchen needs. With its new innovative metal kneading hook, powerful 1300-W motor and one-touch auto button for dough, making bread has never been so easy.

Baking homemade breads and cakes is now so simple

- Double metal balloon beater for cream and egg whites
- Metal kneading hook for perfect bread dough
- Blade unit for mixing and blending cake batters

Confidently control power and speed settings

- PowerChop technology for superior chopping performance
- One-touch auto buttons for bread dough, whipping and ice

Easy processing and effortless cleaning

- XXL 18-cm discs for faster processing of all ingredients
- Dishwasher-safe accessories
- Large-capacity bowl and blender jar for the whole family

Carefully selected accessories for best results

- Reversible disk for shredding (fine and coarse)
- Citrus press for fresh orange or grapefruit juice



asimpleswitch.com

Highlights

Double metal balloon beater



The double metal balloon beater together with the one-touch auto button creates fluffy egg whites (up to 600% volume increase) and perfectly whipped cream (up to 200% volume increase). Creating delicious desserts has never been easier!

Innovative metal kneading hook



Together with the strong motor, this metal kneading hook quickly forms a dough ball from your ingredients. Once the dough is formed, the innovative kneading hook works the dough with the right force and power so you can make the tastiest bread.

Blade unit


Blade unit for mixing and blending cake batters

PowerChop technology



PowerChop technology is a combination of blade shape, cutting angle and inner bowl that provides a superior chopping result for both soft and hard ingredients. It is also perfect for making purées and mixing your cake batters!

One-touch auto buttons



In addition to the manual 12 speed + pulse control, this Avance Food Processor comes with 3 one-touch auto buttons. To select them, simply turn the control dial to the "ON" position and press the one-touch auto button. The motor then automatically sets the right speed and auto pulse functions for the best results.

Dishwasher-safe accessories



All Philips Food Processor accessories included in your box are dishwasher safe.

XL bowl and blender jar



The extra-large 3.4 litre bowl has a working capacity of 2 litres to handle up to 7 servings of soup, 7 eggs whites or 1.7 kg of dough. A 2.2 litre blender jar handles 1.5 litres of ingredients for up to 5 smoothie portions in one go.

XXL Discs for faster processing

Thanks to the XXL discs (18 cm), the Philips food processor will provide you with faster performance, saving you time and effort while cooking.

Reversible disk for shredding



The reversible shredding disk (fine and coarse) is suitable for all types of vegetables.

Citrus press for fresh juice



Reliable, simple and beautifully designed, the new Philips Jamie Oliver Food Processor boasts a number of useful accessories for creating fresh and healthy breakfasts, lunches and dinners. This accessory is ideal for extracting fresh juice from citrus fruits such as oranges and grapefruit.



[asimpleswitch.com](https://www.asimpleswitch.com)

Philips Green Logo

Philips Green Products can reduce costs, energy consumption and CO2 emissions. How? They offer a significant environmental improvement in one or more of the Philips Green Focal Areas — Energy efficiency, Packaging, Hazardous substances, Weight, Recycling and disposal and Lifetime reliability.

Specifications

Accessories

Adjustable slicing disc: 1-7 mm

Citrus press

Double balloon beater

Metal kneading hook

Spatula

Stainless steel S-blade

Blender Jar

Reversible disc: slicing/shredding(coarse/fine)

Design specifications

Bowl including lid: SAN

Citrus press: PP

Housing: ABS

Kneading tool: POM and metal

Pusher: ABS

Speed knob: ABS

S-blade, knife, metal discs: Stainless steel

Knife holder, balloon beater: POM

General specifications

Speeds: 12 + pulse

Cord length: 1 m

Functions: 30+

Integrated cord storage

3 preset buttons

Non-slip feet

RPM-Blender&Grinder Mill(max): Up to 20000 rpm

RPM-Blender&Grinder Mill(min): Up to 6500 rpm

RPM-Bowl(max): Up to 1700 rpm

RPM-Bowl(min): Up to 575 rpm

Bowl max working capacity: 2.4 l (dry/liquid)

Bowl capacity: 3.4 l

Bowl max working capacity: 1000g (Flour)

Blender jar working capacity: 1.5 L

Main unit with bowl: 289 x 254 x 436 mm

blender jar capacity: 2.2 L

Technical specifications

Power: 1300 W

Frequency: 50/60 Hz

Voltage: 220-240 V

Safety: Lid and bowl detection, mechanical 1.5 sec brake

Cord length: 1.2 m

Blender jar max capacity: 2.2 L

Blender jar working capacity: 1.5 L

Bowl max capacity: 3.4 L

Bowl working capacity: 2 l

