



**Saeco Exprelia Evo
Super-automatic
espresso machine**

- Brews 7 coffee varieties
- Integrated milk jug & frother
- Stainless steel
- 5 step adjustable grinder



HD8855/01

Perfect, hot, clean.

That's the premium milk froth experience

Only the Saeco Exprelia EVO espresso machine delivers the ultimate milk experience thanks to the new H2 Technology Milk Carafe and the full bean to cup customization

Advanced technology designed for coffee perfection

- Extract maximum flavor with the 100% ceramic grinders

High comfort is part of the experience

- The fully removable brewing group can be cleaned in no time

A variety of coffees customized to your taste

- Fine-tune the coffee's richness with 8 grinder settings
- The strength selection remembers just how strong you like it
- Enjoy a crema layer as you like it with a twist of a knob

PHILIPS

Saeco, a Philips brand

 **Saeco**



Highlights

100% Ceramic grinders



The robust 100% ceramic grinders guarantee a moment of pure coffee indulgence for years to come. The ceramic material creates the ideal grind, which allows the water to flow through steadily, extracting the purest essence of the beans. And unlike other 'regular' grinders', the ceramic material prevents the coffee from overheating and tasting burnt.

Removable brewing group



Efficiency and ease of use were key inspirations when Saeco invented the first brewing group 30 years ago. And to this day, it still proves to be an inspired, resolute piece of technology. As always, it's so simple to clean – just remove it and wash it under the tap for a few seconds, then re-insert it just as easily.

Fine-tune the coffee's flavor



When it comes to the fineness of the grind, this machine never fails to satisfy. Different coffee blends require different levels of granularity for the full flavor to unfold. So the grind granularity of this machine has eight adjustable settings – from the finest grind for a full-bodied espresso, to the coarsest for a lighter coffee

Memo Function



Once you've chosen your ideal strength from the 5 different settings, you can easily save it with the Memo Function, as well your desired length and temperature. Then every cup in the future will be customised exactly to your taste. You'll never have to remind it again, unlike the local barista.

Refine crema and body quality



Enjoy a crema layer just the way you like it and discover a wide spectrum of tastes, all with the twist of a knob! You control the coffee flow and brew pressure to vary the body and thickness of the crema with one easy move. Turn it left for a luxurious, thick crema layer and an intense and full bodied espresso; Or turn it right for a smooth, lighter tasting coffee with less crema.



asimpleswitch.com

Philips Green Logo

Philips Green Products can reduce costs, energy consumption and CO2 emissions. How? They offer a significant environmental improvement in one or more of the Philips Green Focal Areas – Energy efficiency, Packaging, Hazardous substances, Weight, Recycling and disposal and Lifetime reliability.

Super-automatic espresso machine

Brews 7 coffee varieties Integrated milk jug & frother, Stainless steel, 5 step adjustable grinder

HD8855/01

Specifications

Technical specifications

- Pump pressure: 15 bar
- Capacity milk carafe: 500 ml
- Capacity bean container: 300 gr
- Capacity waste container: 11 servings
- Max. cup height: 150 mm
- Brewing time one cup: 45 (espresso) to 100 (long coffee) sec
- Water boilers: 2
- Voltage: 230 V
- Frequency: 50 Hz
- Cord length: 0.8 m
- Capacity water tank: 1.5 L

Sustainability

- Power consumption brewing: 1400 W

General specifications

- Cups at the same time: 2
- Compatible coffee serving: Whole coffee beans, ground coffee powder
- One touch variety: 7
- Coffee strength settings: 3
- Temperature settings: 3
- Grinder settings: 8
- Type of carafe: Basic carafe
- Type of display: LCD
- Special functions: Ceramic grinder, Integrated carafe, Pre-brewing, Ground coffee option, Crema adjustment knob

- Customizing per drink: Adjustable coffee strength, Adjustable temperature, Adjustable cup volume, Adjustable amount milk foam
- Ease of use and comfort: Removable water tank, Display, Adjustable spout, Removable drip-tray, Automatic stand-by, Automatic shut-off
- Ease of cleaning & maintenance: Automatic de-scaling cycle, Removable brewing group, Automatic carafe cleaning, Automatic rinse cycle
- Coffee drinks: Espresso, Cappuccino, hot water, Café Crème, frothed milk, Espresso Macchiato, Latte Macchiato

Finishing

- Material boiler: Stainless steel (Inox)
- Material drip tray: Stainless steel
- Material of main body: Stainless steel
- Material water tank: Plastic

Country of origin

- Made in: Italy

Service

- 1-year guarantee

Weight and dimensions

- Weight of product: 16.1 kg
- Dimensions of product (WxDxH): 245 x 420 x 360 mm

Issue date 2019-03-18

Version: 8.1.1

© 2019 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com



asimpleswitch.com