



Philips PerfectCare Elite  
Refurbished Steam  
generator iron

#### Refurbished product

Max 6.7-bar pressure  
Up to 470 g steam boost  
Detachable 1.8 l water tank



GC9630

## The most powerful steam for the fastest ironing\* with ultra-light iron

PerfectCare Elite is Philips' best and most efficient steam generator iron. With OptimalTEMP technology, you can now iron everything from jeans to silk with no temperature setting needed. Guaranteed no burns on all ironable garments.

#### **No temperature setting needed; no burning, guaranteed**

- Go from ironing jeans to silk; no need to change temperature setting
- Safe to leave the hot soleplate on the ironing board

#### **Fast ironing with continuous powerful steam**

- Easy and efficient descaling system
- Philips' best gliding and most scratch-resistant soleplate
- Save energy with ECO mode
- Powerful steam for ultimate crease removal

#### **Ultimate ironing experience**

- Lightweight and comfortable to handle
- Large detachable water tank for easy refilling
- Safe and secure carry lock
- Automatic switch-off for safety and energy saving

# PHILIPS

# Highlights

## OptimalTEMP technology



With OptimalTEMP technology you'll no longer have to waste time changing temperature settings, waiting for the temperature to adjust or pre-sorting clothes. Iron all fabrics, from jeans to silk, with no burning guaranteed thanks to the perfect combination of temperature and continuous powerful steam.

## Safe rest



Innovative OptimalTEMP technology guarantees no burning on any ironable fabric. As well as the reassurance this provides whilst ironing, it also means you can leave the hot iron soleplate directly on your cotton ironing board without causing any damage. This helps to reduce any discomfort to your wrists, as you won't need to lift the iron to and from its base as often.

## Easy De-Calc Plus



Regular descaling protects your iron and ensures you'll continue to get the very best steam performance. The exclusively designed and ideally positioned Easy De-Calc Plus function provides the ideal way to get rid of limescale and extend the lifespan of your steam generator iron. The iron will remind you with both light and sound when it's time to clean and descale. Then when your appliance is cold, simply remove the Easy De-Calc knob, collect the dirty water and scale into a cup and discard.

## T-ionicGlide soleplate



The T-ionic Glide is Philips' most premium soleplate, promising superior gliding for faster, effortless ironing. It has a stainless steel base which is harder and more durable than aluminium, with an integrated titanium oxide layer for advanced scratch resistance. Plus the carefully designed shape and vents provide

even better steam distribution for faster crease removal.

## Energy saving



ECO mode allows you to save energy without compromising your ironing results. The ECO mode uses a reduced amount of steam, but still a sufficient amount to iron all your garments.

## Ultra-powerful steam



An ultra-fast ironing experience can be yours with revolutionary technology. The powerful and continuous steam tackles even tough creases, and thicker fabrics are smoothed out with ease and speed. Plus there's an extra steam boost if needed, perfect for vertical steaming or stubborn creases.

# Specifications

## Technology

- Cyclonic steam chamber
- For all ironable fabrics
- No burns
- No temperature settings needed
- OptimalTEMP technology
- Smart Control Processor

## Fast crease removal

- Continuous steam: Up to 135 g/min
- Power: Max 2400 W
- Pressure: Max 6.7 bar
- Ready to use: 2 min
- Steam boost: Up to 470 g
- Steam-on-demand
- Variable steam levels
- Vertical steam
- Voltage: 220 - 240 V

## Easy to use

- Safe on all ironable fabrics: Even delicates like silk
- Soleplate gliding performance: 5 stars
- Soleplate name: T-ionicGlide
- Water tank capacity: 1800 ml
- Detachable water tank
- Hose length: 1.7 m
- Low water alert
- Power cord length: 1.8 m
- Precision steam tip
- Ready to use: Light indicator, Sound indicator
- Refill anytime during use

- Safety auto off
- Soleplate scratch resistance: 5 stars
- Tap water suitable
- Heat-up time: 2 min
- Extra-large filling hole

## Scale management

- Descaling and cleaning: Easy De-calc Plus
- Descaling reminder: Light, Yes

## Storage

- Carry lock: For transportation and safety
- Cord storage: Cord storage compartment, Velcro fix
- Hose storage: Hose storage compartment

## Size and weight

- Packaging dimensions (W x H x D): 31 x 35 x 51 cm
- Product dimensions (W x H x D): 23.3 x 28.5 x 45.3 cm
- Weight of iron: 0.8 kg
- Weight of iron + base: 5.1 kg

## Guarantee

- 2 year worldwide guarantee

## Green efficiency

- Energy saving mode
- Product packaging: 100% recyclable
- User manual: 100% recycled paper



Issue date 2020-10-21

Version: 1.0.1

12 NC: 0000 041 01937  
EAN: 87 10895 68305 0

© 2020 Koninklijke Philips N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips N.V.  
or their respective owners.

[www.philips.com](http://www.philips.com)

\* Iron weight & steam rate (norm IEC60311), vs. the 10 best-selling steam generators; tested Dec. 2014