

# PHILIPS

Steam generator  
iron

PerfectCare  
Performer

Max 6.5-bar pump pressure

Up to 410 g steam boost

SoftGrip

1.8 l detachable water tank



GC8733/20



## Powerful continuous steam for ultra-fast ironing Quiet technology and 1.8-l detachable water tank

The Philips PerfectCare Performer steam generator iron ensures a truly simple, powerful and burn-free ironing experience. The powerful continuous steam penetrates deeply and continuously into the fibre to remove creases easily.

### Carefree ironing, no temperature setting required

- Enjoy powerful ironing with minimal sound
- Iron everything from jeans to silk with no temperature setting required
- Safe to leave the hot soleplate on the ironing board
- Tested and approved by independent textile experts

### Fast and powerful ironing

- SoftGrip: Amazingly comfortable handle
- Compact ProVelocity Steam Engine: continuous steam, all the time
- Continuous steam up to 120 g/min
- 1.8-l detachable water tank, up to 2 hours of ironing
- Tap water-friendly, refill any time during ironing
- Smart Calc cleaning system with a sound and light cleaning reminder
- Ready to use in 2 minutes with unlimited refill
- Saving energy with ECO mode
- Lighter weight steam generator from Philips



asimpleswitch.com

# Highlights

## 1.8 l detachable water tank

The water tank can be removed to be refilled easily under the tap. The large filling hole makes refilling fast. Thanks to the 1.8-l water tank capacity, you can iron for up to 2 hours continuously without any refills.

## ProVelocity Steam Engine

Water is transferred from the water tank to the iron by a high-pressure pump. A lot of water travels inside the steam chamber at very high speed. This causes very powerful and constant steam to come out from the soleplate all the time, without water condensation.

## Continuous steam

The more steam, the faster the ironing. The unique technology in a Philips steam generator iron generates powerful steam making ironing easier, better and faster.

## Energy saving

By using ECO mode and a reduced amount of steam, you can save energy without compromising on the ironing results.

## Lighter weight steam generator

Thanks to the revolutionary ProVelocity technology, we made your steam generator iron more compact than ever before. The compact steam generator fits easily on your ironing board making your ironing more convenient. In addition, your steam generator takes much less storage space.

## OptimalTEMP technology

"Now you can iron from jeans to silk with no temperature setting required. Guaranteed not to burn any ironable fabrics. Revolutionary technology with the 1) Advanced Smart Control Processor which controls precisely the soleplate temperature. You do not need to adjust the temperature 2) Compact ProVelocity steam engine delivers more steam for faster ironing. It features a compact design for easier storage"

## Refill with tap water any time

Your steam generator iron is designed to use tap water. While ironing, when the water tank runs out of water, you can easily refill it without having to wait or turn off your appliance.

## Safe rest

The innovative Philips OptimalTEMP technology guarantees no burns on all ironable fabrics. During ironing, there is no need to put your iron back on the base station; just leave the hot iron soleplate directly on the garments or cotton ironing board cover without an additional resting accessory. It will not damage any of your ironable garments, or the board. This makes your ironing easier, with less wrist effort.

## Smart Calc cleaning system

The Smart Calc cleaning system is an integrated descaling and cleaning function that protects your steam generator iron. After around 10 hours of ironing, your steam generator iron will remind you to perform the Calc cleaning process with a sound and light notification. The iron conveniently rests on the Calc container as it collects the dirty water, so you don't have to strain to hold the iron during the process. After all the water has been collected in the container, your steam generator iron is ready to use again.

## Steam ready in 2 minutes

Steam is ready to use in 2 minutes and can be refilled at any time during ironing.

## Tested and approved:

This iron is tested and approved by independent textile expert institutes, such as DWI, IWTO and Woolmark, for its excellent ironing performance. The Woolmark Apparel Care programme helps consumers to identify quality laundry products that are approved by The Woolmark Company for use on wool products. Philips, with its exclusive OptimalTEMP technology, is so far the only brand to be certified with the Gold standard

from Woolmark. You can be confident that Woolmark-approved apparel care products are ideal for any wool garments.

## Amazingly comfortable handle

The soft material finishing applied on the top of the ironing handle delivers a soft touch. The special pattern to enhance the grip makes gripping more comfortable during ironing

## Max 6.5-bar pump pressure

The more steam, the faster the ironing. Powerful continuous steam is generated, which penetrates deep inside the garments, making ironing faster and better. The amount of steam can be regulated to suit your needs.

## Quiet pump

Enjoy ironing with family around or while watching TV, without being disturbed by the noise of your steam generator. Quiet technology delivers quiet yet very powerful steam. The steam generator is fitted with a sound-absorbing platform to reduce the noise caused by the pump vibration while delivering the powerful continuous steam.



[asimpleswitch.com](https://www.asimpleswitch.com)

## Philips Green Logo

Philips Green Products can reduce costs, energy consumption and CO2 emissions. How? They offer a significant environmental improvement in one or more of the Philips Green Focal Areas — Energy efficiency, Packaging, Hazardous substances, Weight, Recycling and disposal and Lifetime reliability.

---

# Specifications

## Technology

For all ironable fabrics  
No burn  
OptimalTEMP Technology  
ProVelocity steam engine  
Smart Control Processor  
Quiet pump

## Fast crease removal

Continuous steam: Up to 120 g/min  
Power: 2600 W  
Pressure: Max 6.5-bar pump  
Ready to use: 2 min  
Steam boost: Up to 410 g  
Steam-on-demand  
Variable steam levels  
Vertical steam

## Easy to use

Safe on all ironable fabrics: Even delicates like silk  
Soleplate gliding performance: 5 stars  
Soleplate name: SteamGlide Plus  
Detachable water tank  
Hose length: 1.6 m  
Power cord length: 1.8 m  
Precision steam tip  
Ready to use: Light indicator, Sound indicator  
Refill anytime during use  
Safety auto off  
Soft grip  
Soleplate scratch resistance: 4 stars

## Scale management

Descaling and cleaning: Smart Calc Clean  
Descaling reminder: Light, Sound, Yes

## Storage

Carry lock: For transportation and safety  
Cord storage: Velcro fix, Yes  
Hose storage: Hose storage compartment

## Size and weight

Product dimensions (W x H x D): 22 x 24 x 37 cm  
Weight of iron: 1.22 kg  
Weight of iron + base: 3.2 kg

## Guarantee

2 year worldwide guarantee

## Green efficiency

Energy saving mode  
Product packaging: 100% recyclable  
User manual: 100% recycled paper

