



Philips  
Handheld vacuum cleaner

• 3.6 V



FC6050

## Easy cleaning anywhere

Vacuum cleaner with precision nose piece

The specially designed Philips FC6050 (3.6 V) vacuum cleaner, cleans anywhere easily, thanks to its extended nose piece. The FC6050 has 3 powerful rechargeable batteries that give you the freedom of efficient cordless cleaning.

### **Easily cleans in corners and along curves**

- Extended nose piece

### **Cordless cleaning power wherever you want**

- Powerful rechargeable batteries

### **Lasting suction power**

- 2-stage filter system prevents early clogging

### **Easily cleans delicate surfaces and narrow spaces**

- Brush tool and crevice tool

# PHILIPS

Handheld vacuum cleaner  
3.6 V

## Highlights

### Extended nose piece



The Philips Mini Vac FC6050 series has a long, narrow nose especially designed for precision cleaning. The extended nose piece makes it easy to clean in corners and along curves.

### Powerful rechargeable batteries



The Philips Mini Vac's rechargeable battery gives you the freedom of cordless cleaning wherever you want.

### 2-stage filter system prevents early clogging



The Philips Mini Vac's 2-stage filtration system ensures that, once inside, dirt cannot escape. The first filter blocks most dirt, while the pleated, second filter traps the finer dust particles.

### Brush tool and crevice tool



The Philips Mini Vac comes with a number of accessories to tackle any job with ease. The soft brush attachment is gentle on delicate surfaces and the crevice tool lets you clean even those awkward, hard-to-reach places.

FC6050/99

## Specifications

### Design

- Color: Spicy orange

### Filtration

- Dust capacity: 0.3 l
- Filter type: Permanent washable
- Filter system: 2-stage

### Performance

- Airflow (max): 620 l/min
- Battery voltage: 3.6 V
- Charging time: 16-18 hour(s)
- Noise level (Lc IEC): 77 dB
- Runtime: 9 minute(s)
- Suction power (max): 6.1 W
- Vacuum (max): 1.9 kPa

### Usability

- Special features: Charging indication

### Weight and dimensions

- Dimensions of A-box (LxWxH): 402 x 397 x 453 mm
- Appliances per A-box: 6
- Dimensions of packaging (LxWxH): 419 x 125 x 190 mm
- Weight of product: 1.2 kg



Issue date 2013-05-09

Version: 3.4.1

12 NC: 0000 000 00000

© 2013 Koninklijke Philips Electronics N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips  
Electronics N.V. or their respective owners.

[www.philips.com](http://www.philips.com)