

# PHILIPS

## Saeco

Super-automatic  
espresso machine

Xsmall

Classic Milk Frother

Black



HD8743/13



## Taste the aroma of your favourite coffee beans one-touch bean-to-cup espresso

Everything you need to embark on a never-ending aroma discovery

### Authentic Italian coffee perfection

- Coffee without burnt taste thanks to 100% ceramic grinders

### Set the beverages to suit your taste

- Save your favourite coffee length
- Play with the coffee's richness with our adjustable grinders

### Easy to clean and maintain

- Always a clean machine thanks to automatic circuit cleaning
- Easy cleaning thanks to removable brewing group

## Highlights

### Automatic circuit cleaning



Saeco designed this espresso machine to automatically clean its coffee circuit with water when the machine is started up or switched off. This delivers a great, fresh taste with each cup of coffee.

### 100% ceramic grinders



This espresso machine is equipped with 100% ceramic grinders. Saeco uses ceramic grinders because of their consistent grind without overheating the coffee bean, for an impeccable espresso. Ceramic also ensures long-lasting performance and totally silent operation.

### Saves your coffee length



You will always get a perfect cup of espresso brewed according to your personal preference thanks to our memo function, which allows you

to adjust the coffee length to suit your taste. Enjoy a superb coffee drink at the touch of a button.

### 5-step adjustable grinders



Different coffee blends require different levels of granularity for the full flavour to unfold. The grind granularity of this espresso machine can be adjusted in 5 settings, from the finest grind, for a full-bodied espresso, to the coarsest, for a lighter café crème.

### Removable brewing group



The brewing group, a Saeco invention, is the heart of our espresso machines, ensuring automation. The brewing group is, depending on the model, easily accessible from the front or side. It can be removed effortlessly for easy cleaning by rinsing under the tap, ensuring maximum hygiene.

## Specifications

### Perfect Espresso

**Espresso technology:** Aroma-system: pre-brewing

### Easy to use

**Cleaning and maintenance:** Automatic coffee circuit rinse

**Usage:** Removable brewing group, Removable water tank

### Technical data

**Boiler:** Stainless steel

**Frequency:** 50 Hz

**Power:** 1400 W

**Voltage:** 230 V

**Pump Pressure:** 15 Bar

### Weight and dimensions

**Maximum cup height:** 95 mm

**Product dimensions (L x D x H):**

420 x 325 x 295 mm

**Coffee bean capacity:** 180 gr

**Dump box capacity:** 8 servings

**Water tank capacity:** 1 l

