



Gaggia  
Manual Espresso  
machine

- Gaggia Baby
- Twin
- Stainless steel

RI9301/21



## BABY TWIN IS THE JEWEL OF THE BABY RANGE

YOUR BARISTA AT HOME

The Gaggia Baby Twin comes with a double heating system for fast Espresso preparation, a touch ring panel, a rotating milk frother and the traditional Gaggia filter holder. Everything you need for a tasty Espresso with Crema layer.

### **Tradizione...**

- Solenoid valve for easier coffee disposal
- 15 bars pressure for full Espresso taste
- Classic milk frother for a tasty Cappuccino
- Coffee pods compatible
- Stainless steel body for long-lasting performance

### **...in continua evoluzione**

- Program the buttons with your favourite coffee drinks
- Rotating classic milk frother for hassle-free frothing

**GAGGIA**  
MILANO

## HIGHLIGHTS

### Solenoid valve



When switching off your Gaggia Espresso machine, the solenoid valve releases the water pressure completely, allowing the used coffee puck to dry. This ensures easier cleaning after preparing an Espresso.

### 15 Bar



The 15bar pressure of your Gaggia coffee machine will make sure you always get the authentic Espresso taste.

### Classic milk frother



The classic milk frother on this Gaggia Espresso machine, traditionally called

"Pannarello", turns milk into gorgeous milk froth within seconds for a Cappuccino, a Latte Macchiato or more. It also delivers hot water for tea.

### Coffee pods compatible



Our Gaggia manual machines come with a coffee filter for 1 or 2 cups of ground coffee, and a special filter for so called ESE (easy serve Espresso) pods. These ESE pods are perfectly portioned and make it easier to operate a manual Espresso machine.

### Personalize machine buttons



Programme the dispensing buttons on your electronic control panel to suit your own personal coffee taste.

### Stainless steel body



The case of your machine has been skillfully manufactured from stainless steel. This makes your Gaggia more robust, ensures long-lasting performance and is an eye-catcher in every kitchen.

### Rotating classic milk frother



The classic milk frother on this Gaggia Espresso machine, traditionally called "Pannarello", turns milk into gorgeous milk froth within seconds for a Cappuccino, a Latte Macchiato or more. It also delivers hot water for tea and can be easily rotated for hassle-free frothing.

## SPECIFICATIONS

### Weight and dimensions

- Product dimensions: 24,5 x 40,0 x 26,5 cm
- Product weight: 7,5 kg
- Water tank capacity: 1,6 L
- Maximum cup height: 75 mm

### Technical data

- Frequency: 50 Hz
- Power: 1300 W
- Pump Pressure: 15 bar
- Voltage: 230 V
- Boiler: Stainless steel, Anodized

### Design

- Materials and finishing: stainless steel

### Features

- Brita Filter compatible
- Cupwarmer
- Interface: Soft touch button
- Pannarello: Plastic
- Removable watertank
- Simultaneous brewing
- Suitable for pods