

Philips FastCare Compact
Steam generator iron

Max 5.2 bar pump pressure

Up to 220 g steam boost
1.3 L fixed water tank
Carry lock

GC6730



Iron faster with 2x more steam*

Powerful, continuous steam works faster than a steam iron, with an easy-to-refill water tank and quick heat-up. Compact and lightweight for easy storage.

Fast & powerful

- Powerful steam for ultimate crease removal
- Calc-clean container included — no cartridges, no extra cost
- Ceramic soleplate for durability and easy gliding

Compact & convenient

- Lightweight and compact for easy use and storage
- Large tank for long use
- Carry lock for safe and easy transport
- Automatic shut-off when the iron is left unattended

PHILIPS

Steam generator iron
Max 5.2 bar pump pressure Up to 220 g steam boost, 1.3 L fixed water tank, Carry lock

GC6730/36R1

Highlights

Ultra-powerful steam



Strong, continuous steam tackles even the thickest fabrics with ease. Watch stubborn creases melt away with an extra steam boost just where you need it. This extra steam is perfect for vertical steaming to refresh clothes and curtains, too.

Auto shut off



The automatic shut off function automatically switches off your steam generator iron if it has not been used for a few minutes. This saves energy and gives you peace of mind.

Ceramic soleplate



Our durable ceramic soleplate glides well on all garments. It's non-stick, scratch-resistant and simple to keep clean.

1.3 L water tank



A 1.3-liter transparent tank gives you more than 1 hour of continuous use. See clearly how much water is left and refill easily at any time under the tap through the large filling door.

Smart descaling



Our built in descaling system, Smart Calc Clean reminds you when you need to descale. It

includes a container to make descaling easy. This means no cartridges are required and no additional costs.

Compact and convenient



The lightweight, compact size is perfect for storage and fits conveniently on your ironing board. Exclusive ProVelocity technology makes our steam generators smaller and more compact than ever.

Safety carry lock



Lock your iron securely to the base station for easy carrying around the house and to reduce the risk of accidentally touching the hot soleplate.

Specifications

Technology

- ProVelocity steam engine

Fast crease removal

- Continuous steam: Up to 110 g/min
- Power: 2400 W
- Pressure: Max 5.2 bar pump
- Ready to use: 2 min
- Steam boost: Up to 220 g
- Steam-on-demand
- Voltage: 220-240 V

Easy to use

- Soleplate gliding performance: 3 stars
- Soleplate name: Ceramic
- Water tank capacity: 1300 ml
- Hose length: 1.6 m
- Power cord length: 1.65 m
- Ready to use: Light indicator, Sound indicator
- Refill any time during use
- Safety auto off
- Soleplate scratch resistance: 3 stars
- Tap water suitable

Accessories included

- Calc clean container

Scale management

- Descaling and cleaning: Smart Calc Clean
- Descaling reminder: Light, Sound, no cartridges needed, no extra

Storage

- Carry lock: For transportation and safety
- Cord storage: Cord storage compartment
- Hose storage: Hose storage compartment

Size and weight

- Packaging dimensions (WxHxL): 25 x 27 x 40 cm
- Product dimensions (WxHxL): 21 x 23 x 35.4 cm
- Total weight with packaging: 4.1 kg
- Weight of iron: 1.25 kg
- Weight of iron + base: 2.9 kg

Guarantee

- 2 year worldwide guarantee

Green efficiency

- Product packaging: 100% recycable



Issue date 2020-08-11

Version: 2.1.1

12 NC: 0000 041 04651
EAN: 87 10895 69819 1

© 2020 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com

* Compared to Philips steam iron PowerLife