



Saeco Talea  
Super-automatic  
espresso machine

- Giro
- Plus

RI9822/01

# Cafè-enjoyment in elegance awaits you

## Enjoy your espresso

Talea standard line

### **Bean- to-cup customization**

- Adjust coffee length and strength
- Patented adjustable espresso crema and body structure

### **Easy to use**

- Delicious milk froth thanks to the classic milk frother
- Adjustable drip tray
- Cup holder
- Ergonomic in day-by-day operations

### **Ease of cleaning and maintaining**

- Always a clean machine thanks to auto-clean and descaling
- Easy cleaning thanks to removable brewing group

**PHILIPS**

Saeco, a Philips brand

 **Saeco**

# Highlights

## Customize coffee



With Saeco espresso machines you can select your preferred coffee length and ground coffee quantity

## SBS (Saeco Brewing System)



Saeco automatic espresso machine exclusively allows you to adjust your espresso's intensity, altering the crema and body structure as it is dispensed. Simply by turning the knob you can prepare the crema exactly according to your taste. A little knob that makes a big difference.

## Cup holder



With this practical feature you can store your espresso cups and glasses right on the espresso machine - always within reach and conveniently stored without taking up space.

## Cup lift



Manually adjustable drip tray to fit every cup size underneath the coffee dispenser

## Classic milk frother



This Saeco espresso machine comes with the classic milk frother that baristas call a "Pannarello". It dispenses steam and is immersed in milk to prepare gorgeous milk foam. Unleash your inner barista by preparing your delicious milk specialties the traditional way!

## Ergonomy



Saeco is a synonym for convenience: refilling beans or water, emptying the coffee-dump box or the drip tray, all compartments are directly accessible.

## Auto cleaning and descaling



Saeco designed this espresso machine to automatically clean its coffee circuit with water upon starting up or switching off of the machine, this delivers a great, fresh taste with each cup of coffee. Regular descaling prolongs your espresso machine's life. This machine will not only prompt when descaling is needed, the automated descaling process will start on your machine and guides you with clear on-screen messages when you have to intervene. Descaling has never been so easy!

## Removable brewing group



The brewing group, a Saeco invention, is the heart of our espresso machines, ensuring automation. The brewing group is, depending on the model, easily accessible from the front or side. It can be removed effortlessly for easily cleaning by rinsing under the tap ensuring maximum hygiene.

# Specifications

## Perfect Espresso

- Espresso technology: Saeco adapting system, Aroma-system: pre-brewing, SBS: creme adaptor, Cup warmer

## Technical data

- Boiler: Stainless steel
- Frequency: 50 Hz
- Power: 1400 W
- Voltage: 230 V
- Pump Pressure: 15 bar

## Weight and dimensions

- Coffee bean capacity: 250 gr
- Waste container capacity: 14 servings
- Water tank capacity: 1,7 L

## Easy to use

- Cleaning and maintenance: Automatic coffee circuit rinse, Automatic milk circuit rinse, Descaling cycle
- Usage: Adjustable coffee dispenser, Bypass for grinded coffee, Cup holding surface, Frontal access to all function, Instant steam (2 boilers), Removable brewing group, Removable watertank

## Energy saving

- Energy saving: Selectable Eco-mode

## Multi-Beverage

- Milk Variations: Frothing degree adaptor, Integrated auto milk function, Milk quantity selector, Removable milk carafe