

Philips
Pressurised ironing system



GC8280



Great results, minimum effort

Endless, powerful steam with 1.4 litre water tank

Powerful yet surprisingly compact, this ironing system produces non-stop, high pressure steam, making ironing fast and easy. Thanks to the 1.4 litre detachable water tank, you can iron for hours without interruption.

Fast and powerful ironing

- Up to 5 bars of steam pressure for fast ironing
- Ready to use in two minutes
- Continuous steam up to 140 g/min for fast crease removal

Iron for up to three hours without refilling

- Extra-large detachable 1.4 litre water tank

Reaches into tricky areas

- The steam tip lets you iron in hard-to-reach areas

Full control

- LCD display to easily change settings

Smooth gliding

- SteamGlide soleplate for powerful steam and superb gliding

PHILIPS
sense and simplicity

Specifications

Easy set-up and storage

- Cord and hose storage: For a neat storage of cord and hose

Smooth gliding

- SteamGlide soleplate

Longer lifetime

- Calc-Clean: Simply rinse the boiler every 10 ironing sessions
- Inox boiler with external heating element: Anti-corrosion steam chamber

Easily removes creases

- Continuous vertical steam: For hanging fabrics
- Optimal vent pattern: For the best steam distribution

Reaches into tricky areas

- Button groove: Speeds up ironing along buttons and seams
- Steam tip: Lets you iron right into hard-to-reach areas

Comfortable ironing

- Suitable for tap water: The iron is suitable for use with tap water
- Extra-large water inlet: For fast, easy filling
- Steam trigger lock: Gives steam without needing to press down
- Extra long lead for maximum reach: 2.5 m
- Extra long hose for maximum reach: 1.9 m
- Crystal Clear water tank: Highly visible water level

Safe ironing

- Automatic shut-off when iron is left unattended: When iron is left unattended
- Programmable safety shut-off: The iron automatically goes off after a set time
- Overheat safety stop: Prevents the boiler from overheating
- Stable heel rest: Keeps the iron stable when

standing

- Iron lock: Stores the iron safely on its stand
- Four rubber feet: Ensure the stand does not slip

Simpler ironing

- Easy control: Ensures clear feedback on settings
- Water hardness selector: Makes your iron last longer
- Language selector: Lets you choose your preferred language
- Sound on/off selector: To turn sound on or off
- Pre-programmed temperatures: Precise temperature settings for twelve different fabrics
- Rinse reminder: Indicates when the boiler needs to be rinsed

Full control

- Variable steam settings to suit every garment: Variable steam settings to suit every garment
- Iron temperature ready light
- Water tank empty light: Indicator shows when water tank needs refilling
- Steam-ready light: Indicator shows when right steam level is reached

Protects your garments

- Drip-stop system: Keeps your garments spotless while ironing

Technical specifications

- Voltage: 230 V
- Frequency: 50–60 Hz
- Boiler wattage: 1200 W
- Iron wattage: 800 W
- Cord length: 2.5 m
- Hose length: 1.9 m

Weight and dimensions

- Weight (incl. packaging): 6.06 kg
- Dimensions: 350 x 350 x 250 mm
- Pallet: 48 pcs

Highlights

1.4 litre water tank



To make ironing effortless you need a lot of steam. High steam output means a lot of refilling. The extra-large 1.4 l water tank reduces the need for refilling.



Issue date 2009-03-13

Version: 5.0.1

12 NC: 0000 000 00000

© 2009 Koninklijke Philips Electronics N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips
Electronics N.V. or their respective owners.

www.philips.com