



**Saeco GranAroma**  
Fully automatic  
espresso machine

- 14 beverages
- 4 User profiles
- Glossy Black
- Black and white display



**SM6480/00**

## Your personal brew, tailored to you

### Easily personalize your coffee with taste presets

Intuitively personalize aromatic coffees like Cappuccino and Latte Macchiato with preset taste profiles via the CoffeeMaestro menu and enjoy silky milk froth from our external milk carafe - even when making two milk drinks at the same time.

#### Personalized Variety

- 14 world-famous beverages with the touch of a button
- 3 taste presets with CoffeeMaestro
- LatteDuo: prepare and enjoy double servings of any variety
- Change your coffee settings with the Coffee Equalizer™
- 4 profiles: Simply, store your personal taste preferences

#### High Quality Coffee & Technology

- 20,000 cups of finest coffee with durable ceramic grinders
- Optimally-balanced temperature and aroma via Aroma Extract
- DoubleShot setting to boost your drink's intensity
- LattePerfetto for dense milk foam with a fine texture
- Large sealed bean container to keep your beans fresh

#### Convenient Experience & Maintenance

- HygieSteam: automatically removes 99.99% of microorganisms\*
- Up to 5000 cups\*\* without descaling thanks to AquaClean

 **Saeco**

**PHILIPS**

Saeco, a Philips brand



Fully automatic espresso machine  
14 beverages 4 User profiles, Glossy Black, Black and white display

SM6480/00

# Highlights

## 14 world-famous beverages



Explore the world of coffee, from familiar recipes such as Espresso and Cappuccino to specialty coffee drinks like Italian Espresso Macchiato.

## CoffeeMaestro



Personalize your coffee experience by selecting a desired taste profile (Delicato, Intenso, Forte) for your beverage. The coffeemaker automatically adjusts the brewing settings like strength, coffee volume and pre-wetting time, to serve you the right taste.

## Automatic Cleaning\* HygieSteam



Our innovative automatic cleaning system, HygieSteam, removes 99.99% of microorganisms\* with one touch.

## 100% Ceramic Grinders



Our grinders are made of high-tech ceramic: they're exceptionally hard and precise. Fresh beans are gently ground, without risk of overheating. All of the best flavors and aroma are extracted, for 20,000 cups or more of delectable coffee. Easily adjust the grinder with 12 settings.

## AquaClean Water Filter



AquaClean is our patented water filter, designed to improve the quality of your coffee by purifying water. It also prevents scale buildup in the water circuit of your coffee machine. Make up to 5000\*\* cups without descaling by replacing the filter regularly.

## LatteDuo



Prepare and enjoy single or double servings of any coffee recipe with one touch, including Cappuccino or Latte Macchiato.

## Coffee Equalizer™



Get interactive guidance for unlimited personalization, with our Coffee Equalizer™. Craft your coffee the way you prefer by customizing the strength, coffee and milk volume, temperature, milk foam density and add an ExtraShot.

## Aroma Extract



The Aroma Extract system intelligently strikes the optimum balance between brewing temperature and aroma extraction. It does this by keeping the water temperature between 90 and 98°C, while regulating the water flow rate, so you can enjoy delicious coffees.

## DoubleShot function



Boost your drink's intensity with the DoubleShot setting via the Coffee Equalizer or the Forte taste profile on the CoffeeMaestro menu. Two ways to add powerful flavor without the bitterness.

# Specifications

## Accessories

- Included: Measuring scoop, Water hardness test strip, Grease Tube, Milk container, Milk Tube, AquaClean filter

## Country of origin

- Designed in: Italy
- Made in: Romania

## Finishing

- Material of main body: Plastic

## General specifications

- Milk Solution: Latte Perfetto technology
- Dishwasher safe parts: Drip tray & grid, Milk container & lid, HygieSteam container & holder, Coffee Grounds Container, Measuring scoop
- Customizing per drink: Aroma Strength, Coffee Quantity, Milk Quantity, Water Quantity, Drink Temperature, Foam Amount, Extra Shot

## Weight and dimensions

- Dimensions of product (WxDxH): 262 x 383 x 448 mm
- Weight of product: 8.5 - 9 kg

## Customization

- Aroma Strength Settings: 5
- Grinder Settings: 12
- Pre Brew Aroma control
- User Interface: Touch Icons Display
- User Profiles: 4, plus guests
- Temperature settings: 3
- Coffee and Milk Length: Adjustable

## Technical specifications

- Capacity milk carafe: 0.6 L
- Capacity waste container: 12 servings
- Capacity water tank: 1.8 L
- Type of boiler: Stainless steel boiler

- Type of carafe: Milk Container Plastic Lid
- Coffee bean capacity: 300 g
- Waste container: Frontal access
- Water tank: Frontal access
- Filter compatibility: AquaClean
- Drip tray capacity: 500 ml
- Frequency: 50 Hz
- Max. cup height: 150 mm
- Voltage: 230 V
- Color(s): Black
- Cord length: 120 cm
- Pump pressure: 15 bar

## Variety

- Beverages: Espresso, Coffee, Americano, Cappuccino, Latte Macchiato, Caffè Latte, Caffè crema, Ristretto, Espresso Lungo, Espresso Macchiato, Italian Cappuccino, Café au Lait, Milk froth, Warm Milk, Hot water
- Coffee Powder Option
- Double Cup
- Milk Double Cup

## Other features

- Removable brew group
- Aroma Seal
- LED in spout
- Auto-Rinse & Guided descaling
- Quick Heat Boiler

## Service

- 2-year worldwide guarantee

## Sustainability

- ECO setting
- Energy label: B-class
- Power consumption stand-by: <0.5 W
- Power consumption brewing: 1500 W
- Recyclable packaging material: > 95%