

PHILIPS

Steam iron

PowerLife

Steam 40g/min; 130g steam boost

SteamGlide soleplate

Safety Auto off + Anti-calc

2400 Watts



GC2960/50



Built to perform, day after day

With SteamGlide soleplate

For great results day after day, you want an iron that never lets you down. With its new SteamGlide soleplate, constant high steam output and Calc buster pill, this practical iron gives you value for money that lasts!

Easily removes creases

- Continuous steam output up to 40 g/min
- 130 g steam boost to remove stubborn creases easily
- Vertical steam for crease removal in hanging fabrics

Powerful performance

- 2400 Watt enables constant high steam output

Easy gliding on all fabrics

- SteamGlide soleplate is Philips premium soleplate

Longer lifetime

- Calc clean slider to easily remove scale out of your iron
- The calc pill breaks down calc so you can flush away easily

Safe ironing

- Iron switches off automatically when left unattended

Highlights

2400 Watt

2400 W
max

2400 Watt enables constant high steam output.

Up to 40 g/min of steam



Philips steam iron with continuous steam output of up to 40 g/min gives you the perfect amount of steam to efficiently remove all creases.

Steam boost up to 130 g



The steam boost can be used for vertical steaming and tough creases.

SteamGlide soleplate



SteamGlide soleplate is the best Philips soleplate for your steam iron. It has great scratch resistancy, glides excellent and is easy to clean.

Calc clean slider



This steam iron can be operated with normal tap water and the calc clean slider makes it easy to remove any built-up scale out of your iron. To maintain the performance of your Philips steam iron, you should use this scale clean function once a month when using normal tap water.

Calc buster pill

Calc
buster
pill

After time calc builds up in your iron. This pill breaks down the calc in pieces so you can calc clean your iron easily. This cleaning needs to happen once a month.

Automatic shut-off

Safety
auto
off

The iron shuts off automatically when left unattended. If it is left on it's heelrest it will switch off in 8 minutes. When left on the soleplate or on the side, it only takes 30 seconds before the iron shuts off.

Specifications

Fast & powerful crease removal

Soleplate: SteamGlide
Vertical steaming
Variable steam settings
Spray

Comfortable ironing

Cord length: 1.8 m

Easy to use

Water tank capacity: 300 ml
Drip stop
Safety auto off

Cord freedom (swivel): 360 degree cord freedom

Extra stability: Rubber bumper

Power cord length: 1.8 m outside Europe, 1.9 m within Europe

Calc management

Suitable for tap water
Calc clean solution: Double active calc clean

Technical specifications

Power Global: 2400 W
Voltage: 220-240 V

Weight and dimensions

Product dimensions: 29.5 x 11.6 x 19.5
Product weight: 1.2 kg

Crease removal

Continuous steam: Up to 40 gr/min
Steam Boost: Up to 130 gr/min

