

# PHILIPS

Food processor

7000 Series

1300W

Compact 3 in 1 setup

3.4 L bowl



HR7776/91



## Chop, slice, shred, knead, whip and blend Create your favorite recipes with PowerChop & more

This Philips 7000 Series Food Processor is the versatile solution for your kitchen needs. With its new innovative metal kneading hook, powerful 1300 W motor and one touch auto button for dough, making bread has never been so easy.

### **Baking homemade breads and cakes is now so simple**

- Double metal balloon beater for cream and egg whites
- Metal kneading hook for perfect bread dough
- Blade unit for mixing and blending cake batters

### **Confidently control power and speed settings**

- PowerChop technology for superior chopping performance
- One touch auto buttons for bread dough, whipping and ice

### **Easy processing and effortless cleaning**

- XXL 18cm discs for faster execution of all ingredients
- Dishwasher safe accessories
- Large-capacity bowl and blender jar for the whole family

### **Carefully selected accessories for best results**

- Reversible disc for shredding (fine and coarse)
- Citrus press for fresh orange or grapefruit juice



[asimpleswitch.com](http://asimpleswitch.com)

# Highlights

## Double metal balloon beater



The double metal balloon beater together with the one touch auto button creates fluffy egg whites (up to 600% volume increase) and perfectly whipped cream (up to 200% volume increase). Creating delicious desserts has never been easier!

## Innovative metal kneading hook



Together with the strong motor, this metal kneading hook quickly forms a dough ball from your ingredients. Once the dough is formed, the innovative kneading hook works the dough with the right force and power to enable you to make the tastiest bread.

## Blade unit

Blade unit for mixing and blending cake batters


## PowerChop technology



**PowerChop**

PowerChop technology is a combination of blade shape, cutting angle and inner bowl that provides a superior chopping result in both soft and hard ingredients. It is also perfect for making purées and mixing your cake batters!

## One touch auto buttons



In addition to the manual 12 speed + pulse control, this Avance Food Processor comes with 3 one touch auto buttons. To select them, simply turn the control dial to the "ON" position and press the one touch auto button. The motor then automatically sets the right speed and auto pulse functions for the best results.

## Dishwasher safe accessories



All Philips Food Processor accessories included in your box are dishwasher safe.

## XL bowl and blender jar



The extra-large 3.4-liter bowl has a working capacity of 2 liters to handle up to 7 servings of soup, 7 eggs whites or 1.7 kg of dough. A 2.2-liter blender jar handles 1.5 liters of ingredients for up to 5 smoothie portions in one go.

## XXL Discs for faster execution

Thanks to the XXL discs (18cm), the Philips food processor will provide you a faster performance saving you time and effort while cooking.

## Reversible disc for shredding



The reversible shredding disc (fine and coarse) is suitable for all types of vegetables.

## Citrus press for fresh juice



Reliable, simple and beautifully designed, the new Philips Jamie Oliver Food Processor boasts a number of useful accessories useful in creating fresh and healthy breakfasts, lunches and dinners. This accessory is ideal for extracting fresh juice from all types of citrus fruit such as oranges and grapefruit.



[asimpleswitch.com](http://asimpleswitch.com)

## Philips Green Logo

Philips Green Products can reduce costs, energy consumption and CO2 emissions. How? They offer a significant environmental improvement in one or more of the Philips Green Focal Areas – Energy efficiency, Packaging, Hazardous substances, Weight, Recycling and disposal and Lifetime reliability.

# Specifications

## Accessories

Adjustable slicing disc: 1-7 mm  
Citrus press  
Double balloon beater  
Metal kneading hook  
Spatula  
Stainless steel S-blade  
Blender Jar  
Reversible disc: slicing/shredding(coarse/fine)

## Design specifications

Bowl including lid: SAN  
Citrus press: PP  
Housing: ABS  
Kneading tool: POM and metal  
Pusher: ABS

Speed knob: ABS  
S-blade, knife, metal discs: Stainless steel  
Knife holder, balloon beater: POM

## General specifications

Speeds: 12 + pulse  
Cord length: 1 m  
Functions: 30+  
Integrated cord storage  
3 preset buttons  
Non-slip feet  
RPM-Blender&Grinder Mill(max): Up to 20000 rpm  
RPM-Blender&Grinder Mill(min): Up to 6500 rpm  
RPM-Bowl(max): Up to 1700 rpm  
RPM-Bowl(min): Up to 575 rpm  
Bowl max working capacity: 2.4L (dry/liquid)

Bowl capacity: 3.4 L  
Bowl max working capacity.: 1000g (Flour)  
Blender jar working capacity: 1.5L  
Main unit with bowl: 289x254x436 mm  
blender jar capacity: 2.2 L

## Technical specifications

Power: 1300 W  
Frequency: 50/60 Hz  
Voltage: 220-240 V  
Safety: Lid & bowl detection, mechanical 1.5 sec brake  
Cord length: 1.2 m  
Blender jar max capacity: 2.2L  
Blender jar working capacity: 1.5L  
Bowl max capacity: 3.4L  
Bowl working capacity: 2L

