



Philips PerfectCare Aqua
Silence
Refurbished Steam
generator iron

Refurbished product

Up to 6.2 bar pressure
330 g steam boost
2.5-l fixed water tank



GC8651

Ultra fast and quiet ironing

with no temperature adjustment required

Iron any ironable garment from silk, to linen, to cotton, to cashmere...in any order, without having to adjust. Your Philips PerfectCare Iron delivers fast results without risk of burn or shine for all your garments. Truly simple ironing.

Carefree ironing, no temperature setting required

- Silent steam technology: Powerful steam with minimum sound
- Iron everything from jeans to silk with no temperature setting required
- Safe to leave the hot soleplate on the ironing board

Fast and powerful ironing

- Descale your appliance effectively and easily to prolong its lifespan
- Tap water-friendly, refill any time during ironing
- Automatically turned off for peace of mind and energy saving
- Ready to use in 2 minutes with unlimited refill
- Up to 6.2 bar pressure
- Large 2.5 l fully visible water tank
- Our best gliding soleplate
- Saving energy with ECO mode
- Lock your iron securely to the base station

PHILIPS

Highlights

Silent steam technology

Enjoy ironing with family around or while watching TV, without being disturbed by the noise of the steam. Silent steam technology delivers quiet yet very powerful steam. The steam generator is fitted with silencing steam filters to reduce the noise of the steam and a sound-absorbing platform to reduce the noise of the pump in the base.

OptimalTEMP technology

Now you can iron everything from jeans to silk with no temperature setting required. Guaranteed no burn on all ironable fabrics. Revolutionary technology with both the Advanced Smart Control Processor, which precisely controls the soleplate temperature so that you don't need to, and the powerful cyclonic steam chamber, which delivers consistent, powerful steam, making ironing easier and faster.

Easy De-calc

Ultra-long-lasting steam performance: Philips' exclusive Easy De-Calc function provides the ideal way to get rid of limescale and extend the lifetime of your steam generator iron. Your iron will remind you to de-calc with light and sound. When your appliance is cold, simply open the Easy De-Calc knob and collect the dirty water and limescale in a cup.

Energy saving

By using ECO mode and a reduced amount of steam, you can save energy without compromising on the ironing results.

Refill with tap water any time

Your steam generator iron is designed to use tap water. While ironing, when the water tank runs out of water, you can easily refill it without having to wait or turn off your appliance.

Safety carry lock

Your steam generator iron comes with a safety carry lock. You can lock your iron safely on the base,

making it safer and reducing the risk of people touching the hot soleplate. You can also carry the steam generator easily.

Safe rest

The innovative Philips OptimalTEMP technology guarantees no burns on all ironable fabrics. During ironing, there is no need to put your iron back on the base station; just leave the hot iron soleplate directly on the garments or cotton ironing board cover without an additional resting accessory. It will not damage any of your ironable garments, or the board. This makes your ironing easier, with less wrist effort.

Automatic shut-off

The auto-off function automatically switches off the appliance if it has not been used for a few minutes, also saving energy.

Steam ready in 2 minutes

Steam is ready to use in 2 minutes and can be refilled at any time during ironing.

T-ionicGlide soleplate

The 5-star-rated soleplate with integrated Titanium-Oxide layer offers our best gliding performance and is the most scratch resistant

Up to 6.2 bar pressure

The more steam, the faster the ironing. Consistent powerful steam is generated which penetrates deep inside the garments making ironing both faster and better. Steam power can be regulated to suit your needs.

2.5 l fully visible water tank

The extra-large 2.5 L water tank ensures up to 3 hours ironing without any refilling. It makes your ironing faster and easier. Thanks to the clear water tank, you can see the water level from any angle and make sure you still have enough water to steam efficiently.

Specifications

Calc management

- Calc clean reminder
- Calc clean solution: Easy De-calc
- Suitable for tap water

Easy to use

- Cord freedom (swivel): 180 degree cord freedom
- Cord storage: Cord clip
- Heat-up time: 2 min
- Hose length: 1.7 m
- Hose storage: Hose storage compartment
- Low water alarm
- Power cord length: 1.8 m
- Refill any time
- Safe for all fabrics: Even for delicates such as silks
- Safety auto off
- Storage solution: Carry lock
- Water tank capacity: 2500 ml
- Filling and emptying water: Extra-large filling hole

Fast and powerful crease removal

- OptimalTEMP technology
- Power: 2400 W
- Safe rest
- Silent Steam Technology
- Soleplate: T-ionicGlide
- Steam boost: 330 g
- Steam tip
- Vertical steaming
- Pressure: Up to 6.2 bar pressure

Sustainability

- Energy saving mode

Technical specifications

- Voltage: 220 - 240 V
- Product dimensions: 36.2 x 27 x 26.3 cm
- Weight of iron: 1.1 kg
- Weight of iron + base: 4.5 kg



Issue date 2019-12-04

Version: 1.0.1

12 NC: 0000 041 01936
EAN: 87 10895 68304 3

© 2019 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com

* In the category of pressurised unlimited steam generator